



How to change fuel filter
on **AUDI A6 Avant (4A5,
C4) petrol** – replacement
guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle


i Important!

This replacement procedure can be used for:
 AUDI A6 Avant (4A5, C4) 2.8, AUDI A6 Avant (4A5, C4) 2.8 quattro

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: VW PASSAT Variant (3B5) 1.8 T

REPLACEMENT: FUEL FILTER – AUDI A6 AVANT (4A5, C4). LIST OF THE TOOLS YOU'LL NEED:



- All-purpose cleaning spray
- Drive socket # 10
- Ratchet wrench
- Fluid container
- Flat Screwdriver

[Buy tools](#)

Replacement: fuel filter – AUDI A6 Avant (4A5, C4). AUTODOC experts recommend:

- Ensure adequate ventilation of the workplace. Fuel vapors are poisonous.
- All work should be done with the engine stopped.

REPLACEMENT: FUEL FILTER – AUDI A6 AVANT (4A5, C4). RECOMMENDED SEQUENCE OF STEPS:


1 Lift the car using a jack or place it over an inspection pit.

2 Unscrew the fuel filter bracket fastening bolts. Use a drive socket #10. Use a ratchet wrench.




3 Prepare a container for fluids.

4 Clean the fasteners of the fuel supply lines. Use all-purpose cleaning spray.



5 Loosen the fuel supply lines fastening to the fuel filter.




6 Use a flat screwdriver.

Replacement: fuel filter – AUDI A6 Avant (4A5, C4). AUTODOC recommends:

- Be careful! Fuel may leak from the filter housing and hoses.

7 Disconnect the fuel supply lines from the fuel filter.



8 Remove the fuel filter.




9 Put the old filter cartridge in the container.



10 Take out the fuel filter bracket.

11 Install the bracket on a new fuel filter.



12 Install a new fuel filter.

13 Fasten the fuel filter in the holder. Use a flat screwdriver.




Replacement: fuel filter – AUDI A6 Avant (4A5, C4). Tip:

- Make sure that the fuel filter is positioned correctly. Consider the fuel flow direction mark.
- During installation, take care to prevent dust and dirt from getting into the fuel filter housing.
- Take care to only use quality filters.

14

Connect the fuel supply lines to the fuel filter and tighten the fasteners. Use a flat screwdriver.



15

Tighten the fuel filter bracket fastening bolts. Use a drive socket #10. Use a ratchet wrench.



16

Take the fluid container away from under the fuel filter.

17

Lower the car.

Replacement: fuel filter – AUDI A6 Avant (4A5, C4). Tip from AUTODOC experts:

- Before starting off, switch the ignition on and off several times. This should be done to activate the fuel pump to make it pump fuel through the fuel system.

18

Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

19

Shut off the engine.

WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

FUEL FILTER: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.