



How to change fuel filter
on **Audi A4 B6** –
replacement guide

VIDEO TUTORIAL



ⓘ Important!

This replacement procedure can be used for:

AUDI A4 B6 Saloon (8E2) 1.8 T, AUDI A4 B6 Saloon (8E2) 1.8 T quattro, AUDI A4 B6 Avant (8E5) 1.8 T, AUDI A4 B6 Avant (8E5) 1.8 T quattro, AUDI A4 B6/B7 Convertible (8H7, 8HE) 1.8 T, AUDI A4 B6/B7 Convertible (8H7, 8HE) 1.8 T quattro, AUDI A6 C6 Saloon (4F2) 2.4, AUDI A6 C6 Saloon (4F2) 4.2 quattro, AUDI A4 B7 Saloon (8EC) 1.8 T, AUDI A4 B7 Saloon (8EC) 1.8 T quattro, AUDI A4 B7 Avant (8ED) 1.8 T, AUDI A4 B7 Avant (8ED) 1.8 T quattro, AUDI A6 C6 Saloon (4F2) 2.4 quattro, AUDI A6 C6 Avant (4F5) 4.2 quattro, AUDI A6 C6 Avant (4F5) 2.4, (+ 8)

The steps may slightly vary depending on the car design.

REPLACEMENT: FUEL FILTER – AUDI A4 B6. TOOLS
YOU MIGHT NEED:



- All-purpose cleaning spray
- Torx bit T20
- Flat Screwdriver
- Fuel line pliers
- Fluid container

BUY TOOLS

Replacement: fuel filter – Audi A4 B6. Professionals recommend:

- Ensure adequate ventilation of the workplace. Fuel vapors are poisonous.
- Please note: all work on the car – Audi A4 B6 – should be done with the engine switched off.


CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Lift the car using a jack or place it over an inspection pit.




2 Clean the fuel filter housing and the cover. Use all-purpose cleaning spray.

3 Loosen the fuel filter mounting. Use Torx T20.



4 Prepare a container for fluids.



- 5 Squeeze the clips and detach the fuel supply lines from the fuel filter housing. Use fuel line pliers. Use a flat screwdriver.




Replacement: fuel filter – Audi A4 B6. Tip from AUTODOC:

- Be careful! Fuel may leak from the filter housing and hoses.


- 6 Remove the fuel filter.



- 7 Put the old filter cartridge in the container.



- 8 Install a new fuel filter.




Replacement: fuel filter – Audi A4 B6. Professionals recommend:

- Make sure that the fuel filter is positioned correctly. Consider the fuel flow direction mark.
- During installation, take care to prevent dust and dirt from getting into the fuel filter housing.
- Attention! Use quality filters – Audi A4 B6.


9

Connect the fuel lines to the fuel filter and lock the fastening clips.



10

Tighten the fuel filter fasteners. Use Torx T20.



11

Take the fluid container away from under the fuel filter.

12

Lower the car.



Replacement: fuel filter – Audi A4 B6. Tip:

- Before starting off, switch the ignition on and off several times. This should be done to activate the fuel pump to make it pump fuel through the fuel system.

13

Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly. Shut off the engine.

Replacement: fuel filter – Audi A4 B6. AUTODOC recommends:

- To protect the environment from pollution, be sure to dispose of the used filters at special collection points.

WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

The image shows two smartphones displaying the Autodoc mobile app. The left phone shows a search bar, a 'TODAY'S OFFERS' section with a tire and filter, a 'Daily check' section, and a 'CATEGORIES' section with items like 'Axel Mount', 'Steering Whe', and 'Spark, G'. The right phone shows the Autodoc logo and a collection of car parts. To the right of the phones are three buttons: 'GET IT ON Google Play', 'Download on the App Store', and 'Download'.

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR AUDI

FUEL FILTER: A WIDE SELECTION

CHOOSE CAR PARTS FOR AUDI A4 B6

FUEL FILTER FOR AUDI: BUY NOW

FUEL FILTER FOR AUDI A4 B6: THE BEST DEALS & OFFERS

ⓘ DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.