- AUTODOC CLUB

How to change rear shock absorbers on **Honda Civic 8** – replacement guide



VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for: HONDA CIVIC VIII Hatchback (FN, FK) 1.4 (FK1), HONDA CIVIC VIII Hatchback (FN, FK) 2.2 CTDi (FK3), HONDA CIVIC VIII Hatchback (FN, FK) 1.4 (FK1, FN4)

The steps may slightly vary depending on the car design.



REPLACEMENT: SHOCK ABSORBERS – HONDA CIVIC 8. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Ceramic grease
- Torque wrench
- Drive socket # 14
- HEX bit no.H5
- 14-mm strut nut socket

- Shock absorber socket # 16
- Shock absorber socket #DD6
- Wheel impact socket #19
- Ratchet wrench
- Tap wrench
- Hydraulic transmission jack
- Wheel chock

BUY TOOLS





- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- All work should be done with the engine stopped.

REPLACEMENT: SHOCK ABSORBERS – HONDA CIVIC 8. TAKE THE FOLLOWING STEPS:



Open the luggage compartment.



2

Remove the mount cap from the shock absorber upper fastener.



3

Clean the upper fastener of the shock absorber. Use a wire brush. Use WD-40 spray.





Loosen the upper fastener of the shock absorber. Use a 14-mm strut nut socket. Use HEX No.H5. Use a ratchet wrench.



5

Secure the wheels with chocks.

6

Loosen the wheel bolts. Use wheel impact socket #19. Use a tap wrench.



7

Raise the car.



Replacement: shock absorbers – Honda Civic 8. AUTODOC recommends:

- If you are using a jack, make sure it rests on a flat surface without any unevenness.
- Be sure to additionally secure the car with jack stands.





Unscrew the wheel bolts.



AUTODOC recommends:

• Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. Honda Civic 8



Remove the wheel.



10

Clean the lower shock absorber fastener. Use a wire brush. Use WD-40 spray.



11

Support the rear axle beam. Use a hydraulic transmission jack.





Unscrew the lower fasteners of the shock absorber. Use a drive socket #14. Use a ratchet wrench.



13

Unscrew the upper fastener of the shock absorber.



14

Remove the elements of the shock absorber upper mount.



15

Lower the hydraulic transmission jack by 10-15 cm.



Replacement: shock absorbers – Honda Civic 8. Tip:

• Lower the hydraulic transmission jack smoothly, without jerks, to avoid damaging assemblies and mechanisms.

+ AUTODOC CLUB



16

Remove the fastening bolt.





Remove the shock absorber.



18

Clean the shock absorber mounting seats. Use a wire brush.



19

Remove the shock absorber dust boot and bump stop.

AUTODOC recommends:

 Examine the shock absorber dust boot and bump stop. Replace them if necessary.

20

Install the dust boot and the bump stop on the new shock absorber.







Place the shock absorber in the wheel arch and secure it.



Replacement: shock absorbers – Honda Civic 8. AUTODOC experts recommend:

• Before installing a new shock absorber you should pump it 3–5 times by hand.



Install the fastening bolt.



23

Support the rear axle beam. Use a hydraulic transmission jack.



AUTODOC recommends:

• For tightening the fasteners correctly, you have to jack up the suspension components to their working position.

+ AUTODOC CLUB



24

Install the elements of the shock absorber upper mount.



25

Screw the upper fastener of the shock absorber.



26

Tighten the lower fastener of the shock absorber. Use a drive socket #14. Use a torque wrench. Tighten it to 54 Nm torque.



27

Remove the support from under the rear axle beam.



AUTODOC recommends:

• Replacement: shock absorbers – Honda Civic 8. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

+ AUTODOC CLUB



28

Clean the wheel rim mounting seat. Use a wire brush.



29

Treat the surface where the brake disc contacts the wheel rim. Use ceramic grease.



30

Clean the brake disk surface. Use a brake cleaner.



31

Install the wheel.



AUTODOC recommends:

• Important! Hold the wheel while screwing in the fastening bolts. Honda Civic 8



Screw in the wheel bolts. Use wheel impact socket #19. Use a ratchet wrench.



33

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 108 Nm torque.



34

Remove the jacks and chocks.



35

Tighten the top fastener of the shock absorber. Use a special drive socket to remove the shock absorber # 16. Use a shock absorber socket #DD6. Use a torque wrench. Tighten it to 20 Nm torque.





Install the mount cap on the shock absorber upper fastener.



37

Close the luggage compartment.






VIEW MORE TUTORIALS



AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR HONDA

SHOCK ABSORBERS: A WIDE SELECTION



CHOOSE CAR PARTS FOR HONDA CIVIC 8

SHOCK ABSORBERS FOR HONDA: BUY NOW

SHOCK ABSORBERS FOR HONDA CIVIC 8: THE BEST DEALS & OFFERS

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.