+ AUTODOC CLUB


How to change tailgate struts on **Honda Civic 8** – replacement guide







VIDEO TUTORIAL



i Important!

This replacement procedure can be used for:
HONDA CIVIC VIII Hatchback (FN, FK) 1.4 (FK1), HONDA CIVIC VIII Hatchback (FN, FK) 2.2 CTDi (FK3), HONDA CIVIC VIII Hatchback (FN, FK) 1.6, HONDA CIVIC VIII Hatchback (FN, FK) 1.4 (FK1, FN4)

The steps may slightly vary depending on the car design.


CLUB.AUTODOC.CO.UK 1–9











- WD-40 spray
- Flat screwdriver

• Hydraulic transmission jack

BUY TOOLS

CLUB.AUTODOC.CO.UK 2–9







Replacement: tailgate struts – Honda Civic 8. Tip from AUTODOC experts:

- Right and left gas struts of the boot lid should be replaced simultaneously.
- The replacement procedure is identical for the right and left gas struts of the boot lid.
- All work should be done with the engine stopped.

REPLACEMENT: TAILGATE STRUTS – HONDA CIVIC 8. RECOMMENDED SEQUENCE OF STEPS:

1

Open the boot lid.



2

Support the boot lid. Use a hydraulic transmission jack.



CLUB.AUTODOC.CO.UK 3–9

3







Release the circlip connecting the gas strut to the boot lid. Use a flat screwdriver.



AUTODOC recommends:

- To avoid any injuries, be sure to hold the boot lid while demounting the gas struts.
- Release the circlip connecting the gas strut to the car body. Use a flat screwdriver.



- Remove the boot lid gas strut.
- Clean the mounting seats of the boot strut. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 4-9







7 Install the new boot lid gas strut.



Snap on the circlip connecting the gas strut to the car body.



Snap on the circlip connecting the gas strut to the boot lid.



Release the circlip connecting the gas strut to the boot lid. Use a flat screwdriver.



10

Replacement: tailgate struts – Honda Civic 8. AUTODOC recommends:

• To avoid any injuries, be sure to hold the boot lid while demounting the gas struts.

CLUB.AUTODOC.CO.UK 5–9







Release the circlip connecting the gas strut to the car body. Use a flat screwdriver.



- Remove the boot lid gas strut.
- Clean the mounting seats of the boot strut. Use WD-40 spray.



- 14 Install the new boot lid gas strut.
- Snap on the circlip connecting the gas strut to the car body.



Snap on the circlip connecting the gas strut to the boot lid.



CLUB.AUTODOC.CO.UK 6–9







17 Remove the hydraulic transmission jack.



Replacement: tailgate struts – Honda Civic 8. Tip:

• Check the working condition of the boot lid gas springs after they are installed.

18

Close the boot lid.






VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 7–9





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR HONDA

TAILGATE STRUTS: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 8-9





CHOOSE CAR PARTS FOR HONDA CIVIC 8

TAILGATE STRUTS FOR HONDA: BUY NOW

TAILGATE STRUTS FOR HONDA CIVIC 8: THE BEST DEALS & OFFERS

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 9-9