




How to change rear anti
roll bar links on **Honda**
CR-V II – replacement
guide

VIDEO TUTORIAL

** Important!**

This replacement procedure can be used for:
HONDA CR-V II (RD_) 2.0 (RD4)

The steps may slightly vary depending on the car design.

REPLACEMENT: ANTI ROLL BAR LINKS – HONDA CR-V
 II. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #14
- Combination spanner #17
- Drive socket # 14
- Drive socket # 17
- HEX bit no.H6.
- Ratchet wrench
- Torque wrench

BUY TOOLS

AUTODOC recommends:


- Replace the stabiliser links on Honda CR-V II in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- Please note: all work on the car – Honda CR-V II – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:


- 1 Lift the car using a jack or place it over an inspection pit.




- 2 Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.




- 3** Unscrew the fastener connecting the stabilizer link to the control arm. Use a combination spanner #14. Use a drive socket #14. Use a ratchet wrench.




- 4** Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #14. Use a drive socket #14. Use a ratchet wrench.




- 5** Remove the stabilizer rod.




- 6** Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.




7 Install the transverse stabilizer link.




8 Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #17. Use HEX No.H6. Use a torque wrench. Tighten it to 38 Nm torque.



9 Install the rod fastening to the stabilizer and tighten it. Use a combination spanner #17. Use a drive socket #17. Use HEX No.H6. Use a torque wrench. Tighten it to 38 Nm torque.



10 Treat all joints of the stabiliser link. Use copper grease.



11

Lower the car.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON  **Google Play**

 **Download on the App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR HONDA

ANTI ROLL BAR LINKS: A WIDE SELECTION

CHOOSE CAR PARTS FOR HONDA CR-V II

ANTI ROLL BAR LINKS FOR HONDA: BUY NOW

ANTI ROLL BAR LINKS FOR HONDA CR-V II: THE BEST DEALS & OFFERS

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.