# **+** AUTODOC CLUB

How to change spark plugs on **FORD ESCORT IV (GAF, AWF, ABFT)** – replacement guide







#### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

#### (i) Important!

This replacement procedure can be used for: FORD ESCORT IV (GAF, AWF, ABFT) 1.1, FORD ESCORT IV (GAF, AWF, ABFT) 1.3

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FORD MONDEO III Estate (BWY) 1.8 16V

CLUB.AUTODOC.CO.UK 1–7










## REPLACEMENT: SPARK PLUGS – FORD ESCORT IV (GAF, AWF, ABFT). TOOLS YOU MIGHT NEED:



- High-temperature anti-seize lubricant
- Spark plug socket # 16
- Ratchet wrench

- Torque wrench
- Flat Screwdriver
- Fender cover

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-7





## Replacement: spark plugs – FORD ESCORT IV (GAF, AWF, ABFT). AUTODOC recommends:

- The replacement procedure is the same for all spark plugs.
- All work should be done with the engine stopped.

# REPLACEMENT: SPARK PLUGS – FORD ESCORT IV (GAF, AWF, ABFT). TAKE THE FOLLOWING STEPS:

- Open the hood.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Remove the engine cover.



### Replacement: spark plugs – FORD ESCORT IV (GAF, AWF, ABFT). Tip from AUTODOC:

- Raise the engine cover, holding it on two sides simultaneously.
- Do not apply excessive force when removing the part. Otherwise you may damage it.

CLUB.AUTODOC.CO.UK 3-7

4







Remove the spark plug wire connectors from the spark plug wells. Use a flat screwdriver.



## Replacement: spark plugs – FORD ESCORT IV (GAF, AWF, ABFT). AUTODOC experts recommend:

- Be careful to avoid damaging spark plug wires.
- Remember the sequence of the spark plug wires connectors.
- Clean dirt, dust and debris from inside the spark plug wells.
- Unscrew the spark plugs. Use the spark plug socket #16. Use a ratchet wrench.



Take out the spark plugs. Use the spark plug socket #16.



CLUB.AUTODOC.CO.UK 4-7







Apply a thin layer of a special high temperature anti-seize lubricant to the threads of the new spark plugs.



Install the new spark plugs into their mounting seats. Use the spark plug socket #16.



Screw new spark plugs and tighten them. Use the spark plug socket #16. Use a torque wrench. Tighten it to 20 nm torque.



Install the spark plug wire connectors into the spark plug wells. Make sure you hear a click indicating that it is locked in place.



#### **AUTODOC** recommends:

• Follow the installation sequence.

CLUB.AUTODOC.CO.UK 5-7







12 Install the engine cover and secure it.



#### Replacement: spark plugs – FORD ESCORT IV (GAF, AWF, ABFT). Professionals recommend:

- Make sure the engine cover is properly seated. It should not be displaced with respect to the guiding fasteners.
- Do not apply excessive force when installing the part. Otherwise you may damage the fasteners.
- Remove the fender protection cover.
- Close the hood.
- Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.
- Shut off the engine.



**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 6-7





# AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

**SPARK PLUGS: A WIDE SELECTION** 

#### **① DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 7-7