# **+** AUTODOC CLUB

How to change rear brake discs on FORD Focus II Estate (DA\_, FFS, DS) – replacement guide







### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### i Important!

This replacement procedure can be used for:

FORD Focus II Estate (DA\_, FFS, DS) 1.6 TDCi, FORD Focus II Estate (DA\_, FFS, DS) 1.4, FORD Focus II Estate (DA\_, FFS, DS) 1.6, FORD Focus II Estate (DA\_, FFS, DS) 1.6 Ti, FORD Focus II Estate (DA\_, FFS, DS) 1.8 TDCi, FORD Focus II Estate (DA\_, FFS, DS) 1.8 Flexifuel, FORD Focus II Estate (DA\_, FFS, DS) 1.8, FORD Focus II Estate (DA\_, FFS, DS) 1.6 LPG

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FORD MONDEO III Estate (BWY) 1.8 16V

CLUB.AUTODOC.CO.UK 1–15







## REPLACEMENT: BRAKE DISCS – FORD FOCUS II ESTATE (DA\_, FFS, DS). TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Brake caliper guide pins grease
- Copper grease
- Drive socket # 13
- HEX bit no.H7.

- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Brake caliper wind back tool
- Flat Screwdriver
- Crow bar
- Wheel chock

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-15







## Replacement: brake discs – FORD Focus II Estate (DA\_, FFS, DS). Tip from AUTODOC:

- Replace the brake disks on the car FORD Focus II Estate (DA\_, FFS, DS) in complete set for each axis. Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- Warning! Shut down the engine before starting any work FORD Focus II Estate (DA\_, FFS, DS).

### CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:


1

Open the bonnet. Unscrew the brake fluid reservoir cap.



2

Secure the wheels with chocks.



CLUB.AUTODOC.CO.UK 3-15







Loosen the wheel mounting bolts. Use wheel impact socket #19.



- Raise the rear of the car and secure on supports.
- 5 Unscrew the wheel bolts.



Replacement: brake discs – FORD Focus II Estate (DA\_, FFS, DS). AUTODOC recommends:

- To avoid injury, hold up the wheel when unscrewing the bolts.
- Remove the wheel.



CLUB.AUTODOC.CO.UK 4-15







Detach the brake caliper retaining spring. Use a flat screwdriver.



Remove the dust boot caps of the brake caliper guide pins. Use a flat screwdriver.



Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



- 10 Remove the guide pins from the brake caliper.
- Spread the brake pads. Use a crowbar.



CLUB.AUTODOC.CO.UK 5-15







Remove the brake caliper.



## Replacement: brake discs – FORD Focus II Estate (DA\_, FFS, DS). Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them.
   Replace, if necessary.

13 Remove the brake pads.



CLUB.AUTODOC.CO.UK 6-15







Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the caliper bracket fastening. Use a drive socket #13. Use a ratchet wrench.



- Remove the fastening bolts (2 pieces).
- 17 Remove the caliper bracket.



18 Remove the brake disc.



CLUB.AUTODOC.CO.UK 7–15







Clean the hub. Use a wire brush. Treat the contacting surface. Use copper grease.



20 Install the brake disc.



Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



#### **AUTODOC** recommends:

 Replacement: brake discs – FORD Focus II Estate (DA\_, FFS, DS). After applying the spray, wait a few minutes.

Install the brake caliper bracket.



CLUB.AUTODOC.CO.UK 8-15







- 23 Install the fastening bolts (2 pieces).
- Tighten the brake caliper bracket. Use a drive socket #13. Use a torque wrench. Tighten it to 62 Nm torque.



25 Install the brake pads.



Treat the brake caliper piston. Use a brake cleaner.



Replacement: brake discs – FORD Focus II Estate (DA\_, FFS, DS). AUTODOC experts recommend:

• After applying the spray, wait a few minutes.

CLUB.AUTODOC.CO.UK 9-15







27 Press in the brake caliper piston. Use brake caliper wind back tool.



Install the brake caliper and fix it.



Clean the brake caliper guide pins.



Treat the brake caliper guide pins. Use the brake caliper guide pin grease.



31 Screw in the guide pins.



CLUB.AUTODOC.CO.UK 10-15







Tighten the brake caliper fasteners. Use HEX No.H7. Use a torque wrench. Tighten it to 35 Nm torque.



Install the dust boot caps of the brake caliper guide pins.



Install the brake caliper retaining spring. Use a flat screwdriver.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



Clean the brake disk surface. Use a brake cleaner.

36



CLUB.AUTODOC.CO.UK 11-15







#### **AUTODOC** recommends:

 Replacement: brake discs – FORD Focus II Estate (DA\_, FFS, DS). After applying the spray, wait a few minutes.

37

Install the wheel.



Replacement: brake discs – FORD Focus II Estate (DA\_, FFS, DS). Tip from AUTODOC experts:

• To avoid injury, hold up the wheel when screwing in the fastening bolts.

38

Screw in the wheel bolts. Use wheel impact socket #19.



CLUB.AUTODOC.CO.UK 12-15







Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 120 Nm torque.



Remove the jacks and chocks.



#### **AUTODOC** recommends:

- Important! Replacement: brake discs FORD Focus II Estate (DA\_, FFS, DS). Check the brake fluid level in the reservoir and top up if necessary.
- Tighten the brake fluid reservoir cap. Close the hood.

CLUB.AUTODOC.CO.UK 13-15







• Without starting the engine, press the brake pedal several times until you feel significant resistance.



**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 14-15





# AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

**BRAKE DISCS: A WIDE SELECTION** 

### **① DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 15-15