



How to change front
brake discs on **FORD**
Sierra Mk2 Hatchback
(GBC, GBG) –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:
FORD Sierra Mk2 Hatchback (GBC, GBG) 1.8

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FORD Fiesta Mk5 Hatchback (JH1, JD1, JH3, JD3) 1.4 16V

REPLACEMENT: BRAKE DISCS – FORD SIERRA MK2
HATCHBACK (GBC, GBG). TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- HEX bit No.H7.
- Drive socket # 13
- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Brake caliper wind back tool
- Tap wrench
- Crow bar
- Wheel chock

[Buy tools](#)

Replacement: brake discs – FORD Sierra Mk2 Hatchback (GBC, GBG).
AUTODOC experts recommend:

- Replace the brake disks on the car FORD Sierra Mk2 Hatchback (GBC, GBG) in complete set for each axis. Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- All work should be done with the engine stopped.

REPLACEMENT: BRAKE DISCS – FORD SIERRA MK2 HATCHBACK (GBC, GBG). TAKE THE FOLLOWING STEPS:


1

Open the bonnet. Unscrew the brake fluid reservoir cap.



2

Secure the wheels with chocks.



3

Loosen the wheel mounting bolts. Use wheel impact socket #19.




4

Raise the front of the car and secure on supports.

5

Unscrew the wheel bolts.




Replacement: brake discs – FORD Sierra Mk2 Hatchback (GBC, GBG).
AUTODOC recommends:

- To avoid injury, hold up the wheel when unscrewing the bolts.

6

Remove the wheel.



7

Spread the brake pads. Use a crowbar.



8

Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.




9

Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



10

Detach the brake caliper retaining spring. Use a crowbar.



11

Remove the brake caliper.



Replacement: brake discs – FORD Sierra Mk2 Hatchback (GBC, GBG).
Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

12

Remove the brake pads.



13

Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



14

Unscrew the caliper bracket fastening. Use a drive socket #13. Use a tap wrench. Use a ratchet wrench.




15

Remove the caliper bracket.



16

Remove the brake disc.



17

Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.




AUTODOC recommends:

- Replacement: brake discs – FORD Sierra Mk2 Hatchback (GBC, GBG). After applying the spray, wait a few minutes.


18

Clean the hub. Use a wire brush. Treat the contacting surface. Use copper grease.




19

Install the brake disc.



20

Install the brake caliper bracket.



21

Tighten the brake caliper bracket. Use a drive socket #13. Use a torque wrench. Tighten it to 70 Nm torque.



22 Treat the brake caliper piston. Use a brake cleaner.



Replacement: brake discs – FORD Sierra Mk2 Hatchback (GBC, GBG). Tip from AUTODOC:

- After applying the spray, wait a few minutes.

23 Press in the brake caliper piston. Use brake caliper wind back tool.



24 Install the brake pads.




25 Install the brake caliper and fix it. Use HEX No.H7. Use a torque wrench. Tighten it to 30 Nm torque.



26 Install the dust boot caps of the brake caliper guide pins.




27 Install the brake caliper retaining spring.



28 Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



29 Clean the brake disk surface. Use a brake cleaner.



Replacement: brake discs – FORD Sierra Mk2 Hatchback (GBC, GBG). Tip from AUTODOC experts:

- After applying the spray, wait a few minutes.

30

Install the wheel.



AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. FORD Sierra Mk2 Hatchback (GBC, GBG)

31

Screw in the wheel bolts. Use wheel impact socket #19.



32

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 95 Nm torque.



Replacement: brake discs – FORD Sierra Mk2 Hatchback (GBC, GBG).
AUTODOC recommends:

- Check the brake fluid level in the expansion tank and refill if necessary.

33

Tighten the brake fluid reservoir cap. Close the hood.




AUTODOC recommends:

- FORD Sierra Mk2 Hatchback (GBC, GBG) – Press the brake pedal several times with the engine shut down until you feel the resistance built up.

34

Remove the jacks and chocks.



WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BRAKE DISCS: A WIDE SELECTION

(i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.