

How to change air filter on **VW Golf 5** – replacement guide





VIDEO TUTORIAL




(i) Important!

This replacement procedure can be used for:

VW Golf VI Variant (AJ5) 1.6 MultiFuel, VW Golf Plus / Crossgolf (5M1, 521) 1.2 TSI, VW Golf VI Convertible (517) 1.2 TSI, VW Golf VI Convertible (517) 1.4 TSI, VW Golf VI Hatchback (5K1) 1.2 TSI, VW Jetta Mk6 (162, 163, AV3, AV2) 2.0, VW Caddy III Estate (2KB, 2KJ, 2CB, 2CJ) 1.6 BiFuel, VW Caddy III Van (2KA, 2KH, 2CA, 2CH) 1.6 BiFuel, VW Beetle Hatchback (5C1, 5C2) 1.2 TSI, VW Jetta Mk6 (162, 163, AV3, AV2) 1.4 TSI, VW Golf V Hatchback (1K1) 2.0 FSI, VW Touran I (1T1, 1T2) 1.6, VW Touran I (1T1, 1T2) 2.0 FSI, VW Caddy III Van (2KA, 2KH, 2CA, 2CH) 1.6, VW Caddy III Estate (2KB, 2KJ, 2CB, 2CJ) 1.6, (+ 36)

The steps may slightly vary depending on the car design.





O

f





Replacement: air filter – VW Golf 5. Tip from AUTODOC experts:

- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- Warning! Shut down the engine before starting any work VW Golf 5.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:




Open the bonnet.



2

Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.





Undo the fastening screws of the air filter cover. Use a Phillips screwdriver.







4

Take off the filter lid.



5

Unscrew the fasteners of the air filter cartridge. Use a Phillips screwdriver.



6

Remove the filter element from the filter housing.



7

Cover the air intake hose with a microfibre towel to prevent dust and dirt from getting into the system.



8

Clean the air filter cover and housing.







Replacement: air filter – VW Golf 5. AUTODOC experts recommend:

• Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.

9

Remove the microfibre towel from the air intake hose.



10

Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



Replacement: air filter - VW Golf 5. Tip:

- Check out the correct location of the filter element. Do not skew.
- VW Golf 5 It's important to only use high-quality filters.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.





11

Screw in the fasteners of the air filter cartridge. Use a Phillips screwdriver.



12

Reinstall the air filter cover. Fasten it.



13

Screw in the fastening screws of the air filter cover. Use a Phillips screwdriver.



14

Remove the fender protection cover.







15

Close the hood.






VIEW MORE TUTORIALS





AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR VW

AIR FILTER: A WIDE SELECTION



CHOOSE CAR PARTS FOR VW GOLF 5

AIR FILTER FOR VW: BUY NOW

AIR FILTER FOR VW GOLF 5: THE BEST DEALS & OFFERS

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2021 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

(၀)