+ AUTODOC CLUB


How to change air filter on **Fiat Panda 169** – replacement guide







VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for: FIAT PUNTO (188) 1.2 60, FIAT PANDA (169) 1.1, FIAT PANDA (169) 1.2, FIAT PUNTO (188) 1.2 Natural Power, FIAT PANDA (169) 1.2 4x4, FIAT PANDA (169) 1.2 Natural Power, FIAT PUNTO (188) 1.2 Bifuel

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-8







REPLACEMENT: AIR FILTER – FIAT PANDA 169. TOOLS YOU MIGHT NEED:



Microfibre towel

• Fender cover

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-8







Replacement: air filter – Fiat Panda 169. AUTODOC experts recommend:

- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- Please note: all work on the car Fiat Panda 169 should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Open the bonnet.



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



Release the air filter cover clips.




CLUB.AUTODOC.CO.UK 3-8







4 Take off the filter lid.



Remove the filter element from the filter housing.



6 Cover the throttle body with a microfibre towel to prevent dust and dirt from getting into the system.



Clean the air filter cover and housing.



CLUB.AUTODOC.CO.UK 4-8







Replacement: air filter – Fiat Panda 169. Professionals recommend:

• Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.



Remove the microfibre towel from the throttle body.



9

Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



AUTODOC recommends:

- Replacement: air filter Fiat Panda 169. Be sure to position the filtering element correctly. Avoid misalignment.
- Take care to only use quality filters.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.

CLUB.AUTODOC.CO.UK 5-8







10 Reinstall the air filter cover. Fasten it.



Press the air filter cover clips into place.



12 Remove the fender protection cover.



Close the hood.





VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 6-8





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR FIAT

AIR FILTER: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 7-8





CHOOSE CAR PARTS FOR FIAT PANDA 169

AIR FILTER FOR FIAT: BUY NOW

AIR FILTER FOR FIAT PANDA 169: THE BEST DEALS & OFFERS

i DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.

CLUB.AUTODOC.CO.UK 8-8