- AUTODOC CLUB

How to change lambda sensor on **VW Golf 4** – replacement guide



VIDEO TUTORIAL




(i) Important!

This replacement procedure can be used for:

VW Passat Saloon (362) 1.4 TSI, VW Passat Saloon (362) 1.8 TSI, VW Passat Saloon (362) 2.0 TSI, VW Passat Saloon (362) 1.4 TSI EcoFuel, VW Passat Variant (365) 1.4 TSI, VW Passat Variant (365) 1.8 TSI, VW Passat Variant (365) 2.0 TSI, VW Passat Variant (365) 1.4 TSI EcoFuel, VW SHARAN (7M8, 7M9, 7M6) 2.0, VW SHARAN (7M8, 7M9, 7M6) 2.8 VR6, VW Polo Classic (6V2) 1.4, VW Polo Classic (6V2) 1.6, VW Caddy II Van (9K9A) 60 1.4, VW GOLF VI (5K1) 2.0 R 4motion, VW SHARAN (7M8, 7M9, 7M6) 2.8 VR6 Syncro, (+ 218)

The steps may slightly vary depending on the car design.



f

Ø

+ AUTODOC CLUB



Replacement: lambda sensor - VW Golf 4. AUTODOC experts recommend:

- After replacing the oxygen sensor, clear the trouble code from the electronic control unit and let the ECU adapt itself to the new sensor.
- Before getting down to work, start the engine and let it warm up to operating temperature.
- Please note: all work on the car VW Golf 4 should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:



Open the bonnet.



2

Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



+ AUTODOC CLUB



3

Lift the car using a jack or place it over an inspection pit.



4

Unscrew the fasteners of the oxygen sensor housing cover. Use a drive socket #10. Use a ratchet wrench.



5

Remove the oxygen sensor housing cover.



6

Detach the oxygen sensor connector.



7

Unscrew the oxygen sensor fastener. Use a 22-mm oxygen sensor socket. Use a ratchet wrench.



+ AUTODOC CLUB



8

Remove the oxygen sensor.



9

Cut the thread for the new oxygen sensor. Use a thread tap. Use a ratchet wrench.



10

Treat the oxygen sensor. Use high-temperature ceramic grease.

11

Install the new oxygen sensor.



12

Tighten the oxygen sensor fastener. Use a 22-mm oxygen sensor socket. Use a torque wrench. Tighten it to 37 Nm torque.





13

Treat the oxygen sensor connector. Use dielectric grease.



14

Attach the oxygen sensor connector.



15

Install the oxygen sensor housing cover.



16

Screw in the fasteners of the oxygen sensor housing cover. Use a drive socket #10. Use a ratchet wrench.



17

Lower the car.





18

Switch on the ignition. This is necessary in order to make sure that the component operates properly.



19

Switch off the ignition.



21

Remove the fender protection cover.



Close the hood.






VIEW MORE TUTORIALS



AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR VW

LAMBDA SENSOR: A WIDE SELECTION



CHOOSE CAR PARTS FOR VW GOLF 4

LAMBDA SENSOR FOR VW: BUY NOW

LAMBDA SENSOR FOR VW GOLF 4: THE BEST DEALS & OFFERS

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.