

How to change glass for wing mirror on **Skoda Octavia 1Z5** – replacement guide





VIDEO TUTORIAL




(i) Important!

This replacement procedure can be used for:

SKODA Octavia II Combi (1Z5) 1.6 TDI 4x4, SKODA Octavia II Combi (1Z5) 1.6 LPG, SKODA Octavia II Combi (1Z5) 2.0 TDI 16V 4x4, SKODA Octavia II Combi (1Z5) 2.0 TDI, SKODA Octavia II Hatchback (1Z3) 1.9 TDI, SKODA Octavia II Hatchback (1Z3) 2.0 TDI 16V, SKODA Octavia II Hatchback (1Z3) 1.4, SKODA Octavia II Hatchback (1Z3) 1.6, SKODA Octavia II Hatchback (1Z3) 1.6 FSI, SKODA Octavia II Combi (1Z5) 1.6, SKODA Octavia II Combi (1Z5) 1.6 FSI, SKODA Octavia II Combi (1Z5) 1.6, SKODA Octavia II Combi (1Z5) 2.0 TDI 16V, SKODA Octavia II Combi (1Z3) 2.0 FSI, SKODA Octavia II Combi (1Z5) 2.0 FSI, (+ 17)

The steps may slightly vary depending on the car design.





O





Replacement: glass for wing mirror – Skoda Octavia 1Z5. AUTODOC recommends:

• The replacement procedure is identical for the right and left side mirror glass.

• All work should be done with the engine stopped.

REPLACEMENT: GLASS FOR WING MIRROR – SKODA OCTAVIA 1Z5. RECOMMENDED SEQUENCE OF STEPS:



Tilt the mirror glass out of the housing.





Carefully release the mirror glass from its attachment. Use a plastic trim tool.





Remove the mirror glass.







AUTODOC recommends:

• Replacement: glass for wing mirror – Skoda Octavia 1Z5. To avoid damaging the part during installation, do not use excessive force.

4

Detach the mirror heating connectors.



5

Treat the mirror heating connectors. Use dielectric grease.



6

Attach the mirror heating connectors.



7

Install the new mirror glass. Make sure you hear a click indicating that it is locked in place.







Replacement: glass for wing mirror – Skoda Octavia 1Z5. Professionals recommend:

- Do not apply excessive force when installing the part. Otherwise you may damage the fasteners.
- Make sure the mirror glass is positioned correctly. It should be aligned with the locking tabs on the housing.

Clean the mirror glass.



9

8

Switch on the ignition. This is necessary in order to make sure that the component operates properly.









Switch off the ignition.






VIEW MORE TUTORIALS





AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR SKODA

GLASS FOR WING MIRROR: A WIDE SELECTION





CHOOSE CAR PARTS FOR SKODA OCTAVIA 125

GLASS FOR WING MIRROR FOR SKODA: BUY NOW

GLASS FOR WING MIRROR FOR SKODA OCTAVIA 1Z5: THE BEST DEALS & OFFERS

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2021 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.