



How to change air filter
on **Lexus RX XU30** –
replacement guide

VIDEO TUTORIAL


 **Important!**

This replacement procedure can be used for:

LEXUS RX (MHU3_, GSU3_, MCU3_) 3.3 400h, LEXUS RX (MHU3_, GSU3_, MCU3_) 3.3 400h AWD

The steps may slightly vary depending on the car design.

REPLACEMENT: AIR FILTER – LEXUS RX XU30. TOOLS YOU MIGHT NEED:



- All-purpose cleaning spray
- Drive socket # 10
- Ratchet wrench
- Clip removal tool
- Microfibre towel
- Fender cover

BUY TOOLS

Replacement: air filter – Lexus RX XU30. Tip from AUTODOC:

- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- All work should be done with the engine stopped.

REPLACEMENT: AIR FILTER – LEXUS RX XU30. RECOMMENDED SEQUENCE OF STEPS:


1 Open the bonnet.




2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



3 Remove the radiator support cover clips. Use a clip removal tool.




4 Remove the radiator support cover.




5 Loosen the air intake fastening. Use a drive socket #10. Use a ratchet wrench.




6 Loosen the fastening clamp connecting the air duct to the air filter housing. Use a drive socket #10. Use a ratchet wrench.




7 Detach the air duct housing from the air filter housing.



8 Release the air filter cover clips.




9 Take off the filter lid.




10 Remove the filter element from the filter housing.



11 Clean the air filter cover and housing. Use all-purpose cleaning spray.



12 Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



Replacement: air filter – Lexus RX XU30. Professionals recommend:

- Check out the correct location of the filter element. Do not skew.
- Attention! Use quality filters – Lexus RX XU30.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.


13

Clean the air filter cover and housing.




14

Reinstall the air filter cover. Fasten it.




15


Press the air filter cover clips into place.




16 Install the air duct housing.



17 Secure the fastener of the air intake duct. Use a drive socket #10. Use a ratchet wrench.



18 Screw the fastening clamp connecting the air duct to the air filter housing. Use a drive socket #10. Use a ratchet wrench.



19 Install the radiator support cover.



20

Install the radiator support cover clips. Use a clip removal tool.



21

Remove the fender protection cover.



22

Close the hood.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON  **Google Play**

 **Download on the App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR LEXUS

AIR FILTER: A WIDE SELECTION

CHOOSE CAR PARTS FOR LEXUS RX XU30

AIR FILTER FOR LEXUS: BUY NOW

AIR FILTER FOR LEXUS RX XU30: THE BEST DEALS & OFFERS

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.