- AUTODOC CLUB

How to change pollen filter on **SEAT Ibiza IV ST** (6J8, 6P8) – replacement guide



SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for:


SEAT Ibiza IV ST (6J8, 6P8) 1.4 TSI, SEAT Ibiza IV ST (6J8, 6P8) 1.2 TDI, SEAT Ibiza IV ST (6J8, 6P8) 1.2 TSI, SEAT Ibiza IV ST (6J8, 6P8) 1.2, SEAT Ibiza IV ST (6J8, 6P8) 1.4, SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI, SEAT Ibiza IV ST (6J8, 6P8) 1.0, SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI, SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI, SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI, SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI, SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI, SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.4 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.6 TDI SEAT Ibiza IV ST (6J8, 6P8) 1.

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: SEAT Ibiza III Hatchback (6L) 1.4 16V

+ AUTODOC CLUB





REPLACEMENT: POLLEN FILTER – SEAT IBIZA IV ST (6J8, 6P8). TAKE THE FOLLOWING STEPS:



Move the passenger seat fully backwards.





Remove the bottom cover of the glove box.



+ AUTODOC CLUB



3

Release the cabin filter cover clips.



4

Remove the cabin filter housing cover



5

Remove the filter element from the filter housing



AUTODOC recommends:


• Do not attempt to clean and reuse the filter - it will affect the quality of air cleaning inside the car.

6

Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.







+ AUTODOC CLUB





Return the passenger seat to its initial position.





Switch on the ignition.

12 Switch on the air conditioning system. This is necessary in order to make sure that the component operates properly.



Switch off the ignition.





AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

POLLEN FILTER: A WIDE SELECTION

i DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.