



How to change spark
plugs on **SKODA Felicia I
Pickup (6UF, 6U7)** –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:
SKODA Felicia I Pickup (6UF, 6U7) 1.3

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: SEAT Leon Hatchback (1M1) 1.8 20V

REPLACEMENT: SPARK PLUGS – SKODA FELICIA I
PICKUP (6UF, 6U7). TOOLS YOU NEED:



- High-temperature anti-seize lubricant
- Torque wrench
- Spark plug socket # 16
- Ratchet wrench
- Fender cover

Buy tools

AUTODOC recommends:


- The replacement procedure is the same for all spark plugs.
- All work should be done with the engine stopped.

REPLACEMENT: SPARK PLUGS – SKODA FELICIA I PICKUP (6UF, 6U7). USE THE FOLLOWING PROCEDURE:

1 Open the bonnet.

2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.


3 Disconnect the spark plug wires from the spark plugs.




AUTODOC recommends:

- Be careful to avoid damaging spark plug wires.
- Remember the position of the spark plug wires.


4 Clean dirt, dust and debris from inside the spark plug wells.



5 Unscrew the spark plugs. Use the spark plug socket #16. Use a ratchet wrench.




6 Take out the spark plugs.



7 Apply a thin layer of a special high temperature anti-seize lubricant to the threads of the new spark plugs.



8 Install the new spark plugs into their mounting seats.



Replacement: spark plugs – SKODA Felicia I Pickup (6UF, 6U7). AUTODOC experts recommend:

- Lower the spark plugs into the wells carefully, making sure not to damage the electrode gap.

- 9** Screw new spark plugs and tighten them. Use the spark plug socket #16. Use a torque wrench. Tighten it to 26 nm torque.



Replacement: spark plugs – SKODA Felicia I Pickup (6UF, 6U7). Tip:

- Don't tighten the plugs with excessive force. Exceeding tightening torque can damage the thread connection.
- Be careful when working with a spark plug wrench. Its skewing can cause damage to the threaded connection.

- 10** Connect the spark plug wires to the spark plugs.



AUTODOC recommends:

- Replacement: spark plugs – SKODA Felicia I Pickup (6UF, 6U7). Follow the installation steps.

- 11** Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

12 Shut off the engine.

13 Remove the fender protection cover.

14 Close the bonnet.

WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
 **Google Play**

Download on the
 **App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SPARK PLUGS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.