



How to change front
brake caliper on **SKODA
Octavia I Combi (1U5)** –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

SKODA Octavia I Combi (1U5) 1.6, SKODA Octavia I Combi (1U5) 1.8 20V, SKODA Octavia I Combi (1U5) 1.9 SDI, SKODA Octavia I Combi (1U5) 1.9 TDI, SKODA Octavia I Combi (1U5) 1.8 T, SKODA Octavia I Combi (1U5) 1.9 TDI 4x4, SKODA Octavia I Combi (1U5) 2.0, SKODA Octavia I Combi (1U5) 2.0 4x4, SKODA Octavia I Combi (1U5) 1.4 16V, SKODA Octavia I Combi (1U5) 1.8 T 4x4

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: SKODA Octavia II Combi (1Z5) 1.8 TSI

REPLACEMENT: BRAKE CALIPER – SKODA OCTAVIA I COMBI (1U5). TOOLS YOU NEED:



- Wire brush
- Brake cleaner
- Copper grease
- Combination spanner #10
- HEX bit no.H7.
- Drive socket # 11
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Brake hose clip
- Fluid container
- Brake bleeder kit
- Crow bar
- Wheel chock

Buy tools

Replacement: brake caliper – SKODA Octavia I Combi (1U5). AUTODOC recommends:

- The replacement procedure is identical for the left and right brake calipers on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: BRAKE CALIPER – SKODA OCTAVIA I COMBI (1U5). TAKE THE FOLLOWING STEPS:

1 Open the bonnet. Unscrew the brake fluid reservoir cap.

2 Secure the wheels with chocks.



3 Loosen the wheel mounting bolts. Use wheel impact socket #17.



4 Raise the front of the car and secure on supports.

5 Unscrew the wheel bolts.



Replacement: brake caliper – SKODA Octavia I Combi (1U5). Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.

6 Remove the wheel.



7 Put a container for gathering brake fluid beneath.

8 Clean the area where the brake hose is connected to the caliper, and the guide pins area. Use a wire brush. Use a brake cleaner.



AUTODOC recommends:

- Replacement: brake caliper – SKODA Octavia I Combi (1U5). After applying the spray, wait a few minutes.

9

Clamp the brake hose off using a brake hose clamp.




10

Unscrew the brake hose from the brake caliper. Use a drive socket #11. Use a ratchet wrench.




11

Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



12


Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.

**13**

Spread the brake pads. Use a crowbar.

**14**

Remove the retaining spring of the brake pads. Use a crowbar.

**15**

Remove the brake caliper.



Replacement: brake caliper – SKODA Octavia I Combi (1U5). Tip from AUTODOC experts:

- When replacing the brake caliper, it is recommended to check the brake hose for damages and, if necessary, to replace it with a new one.
- When replacing a brake caliper it is recommended to replace brake pads, check the state of the brake discs and replace them with new ones if necessary.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.


16

Remove the brake pads.



17

Install the brake pads.



Replacement: brake caliper – SKODA Octavia I Combi (1U5). AUTODOC experts recommend:

- If going to use the old brake pads, clean them.


18

Install the brake caliper and fix it. Use HEX No.H7. Use a torque wrench. Tighten it to 30 Nm torque.



19

Install the dust boot caps of the brake caliper guide pins.




20

Install the retaining spring of the brake pads.



21

Treat the brake hose. Use a brake cleaner.



Replacement: brake caliper – SKODA Octavia I Combi (1U5). Tip:

- After applying the spray, wait a few minutes.

22 Tighten the fastener connecting the brake pipe to the brake caliper. Use a drive socket #11. Use a torque wrench. Tighten it to 35 Nm torque.



23 Remove the brake hose clamp.



24 Undo the brake bleeder screw. Use a combination spanner #10.



25 Connect the brake bleeder kit to the brake bleeder screw.



- 26 Bleed the brake caliper system. Without starting the engine, press the brake pedal several times until you feel significant resistance.



- 27 Tighten the brake bleeder screw. Use a combination spanner #10.



- 28 Disconnect the brake bleeder kit.



- 29 Tighten the brake caliper bleed screw. Use a drive socket #10. Use a torque wrench. Tighten it to 10 Nm torque.



30 Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



31 Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

- Replacement: brake caliper – SKODA Octavia I Combi (1U5). After applying the spray, wait a few minutes.

32 Install the wheel.



Replacement: brake caliper – SKODA Octavia I Combi (1U5). Tip from AUTODOC:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.


33 Screw in the wheel bolts. Use wheel impact socket #17.



34 Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



35 Remove the jacks and chocks.




AUTODOC recommends:

- Important! Replacement: brake caliper – SKODA Octavia I Combi (1U5). Check the brake fluid level in the reservoir and top up if necessary.

36

Tighten the brake fluid reservoir cap. Close the hood.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BRAKE CALIPER: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.