

How to replace the front brake pads of disc brake on FIAT PUNTO 188

# Carry out replacement in the following order:



Replace brake pads on Fiat Punto 188 in pairs for each axle. It ensures efficient braking

Observe the safety procedures! When brake pads work, brake dust is formed. Therefore, do not use compressed air and do not inhale dust when cleaning the brake pads.



Tighten the parking brake lever.

2


Place wedge blocks under the rear wheels.



Loosen the wheel mounting bolts.

4

Raise the front of the car and secure on supports.



Remove the front wheels.

www.autodoc.co.uk 1–6

6



Using a simple screwdriver, remove the brake caliper spring clip.

7.1



With a simple screwdriver remove caps from both guide pins.

7.2



Ω1



Unscrew the brake caliper fastening

82



9



Remove the brake caliper.

www.autodoc.co.uk 2–6



# How to replace the front brake pads of disc brake on FIAT PUNTO 188

i AutoDoc recommends:

Attach the brake caliper to the suspension or the body by a wire on Fiat Punto 188 without disconnecting the brake hose to avoid the brake system leakage.

Do not press the brake pedal after removing the brake pads. This will lead to the piston drop out of the brake cylinder, brake fluid leakage and the system depressurization.

10.1



Remove the brake pads.

10.2



11

Clean the brake caliper bracket from dirt and dust.

i AutoDoc recommends:

Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

12



With the help of a special tool push in the brake caliper piston to a stop.


www.autodoc.co.uk 3-6

13.1



Install new brake pads

13.2



14.1



Install the brake caliper and fix it.

14.2



14.3



15.1



Install the guide pins covers.

www.autodoc.co.uk 4–6





Install the brake caliper spring



Install the wheel.



Lower the car and working in a cross order, tighten the wheel bolts.

## (i) AutoDoc recommends:

Check the brake fluid level in the expansion tank and refill if necessary.

With the FIAT PUNTO 188 engine off, pump the brake pedal  $\,$ several times until you feel considerable resistance

Slow down smoothly for first 150-200 km after the brake pads replacement. Avoid unneccessary and sharp braking to a stop.

#### Video tutorials

Watch our detailed video guides about your FIAT PUNTO 188 repair on our youtube channel. Watch video guides.

#### AutoDoc online

Highest quality brake pads for your car FIAT PUNTO 188 are available on AutoDoc. Go to the website.

We hope that this information have been useful for you!



# How to replace the front brake pads of disc brake on FIAT PUNTO 188

#### AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE













## i Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement works. AutoDoc shall not be liable for any loss, injury, damage of property, acquired in the repair or replacement process due to incorrect usage or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for informative purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

#### **AUTODOC IN SOCIAL MEDIA**













www.autodoc.co.uk 6–6