How to change rear upper arm on Mercedes ML W163 – replacement guide

VIDEO TUTORIAL

ⓘ Important!

This replacement procedure can be used for:
MERCEDES-BENZ M-CLASS (W163) ML 270 CDI (163.113)

The steps may slightly vary depending on the car design.

REPLACEMENT: REAR UPPER ARM – MERCEDES ML W163. LIST OF THE TOOLS YOU'LL NEED:

- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #13
- Combination spanner #18
- Combination spanner #19
- Combination spanner #21
- Impact socket N°10
- Impact socket N°13
- Impact socket N°21
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Hammer
- Flat Screwdriver
- Hydraulic transmission jack
- Wheel chock

Replacement: rear upper arm – Mercedes ML W163. Tip from AUTODOC experts:

- The replacement procedure is identical for the right and left upper control arms.
- All work should be done with the engine stopped.

REPLACEMENT: REAR UPPER ARM – MERCEDES ML W163. USE THE FOLLOWING PROCEDURE:

1

Secure the wheels with chocks.

2

Loosen the wheel mounting bolts. Use wheel impact socket #17.

3

Raise the rear of the car and secure on supports.

4

Unscrew the wheel bolts.

AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. Mercedes ML W163

5

Remove the wheel.

6



Unscrew the ABS sensor fastening from the steering knuckle. Use a drive socket #10. Use a ratchet wrench.

7

Clean the fastener connecting the ball joint to the steering knuckle. Use a wire brush. Use WD-40 spray.

8

Unscrew the top fastening of the ball joint. Use a combination spanner #19.

9

Disconnect the ball joint from the steering knuckle. Use a hammer.

10

Remove the shock strut mount cap. Use a flat screwdriver.

11

Clean the fasteners of the shock strut upper mount. Use a wire brush. Use WD-40 spray.

12

Loosen the upper fastener of the shock strut mount. Use a combination spanner #13. Use a drive socket #13. Use a ratchet wrench.

13

Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.

14

Unscrew the fastener connecting the stabilizer link to the control arm. Use a combination spanner #13 (2 pieces).

15

Unscrew the fasteners connecting the stabiliser link to the stabiliser bar. Use a combination spanner #13.

16

Unscrew the front arm fastener. Use a combination spanner #18 (2 pieces).

17

Remove the fastening bolt. Use a hammer.

18

Unscrew the rear fastener connecting the control arm to the subframe. Use a combination spanner #18 (2 pieces).

19

Unscrew the lower arm fastening. Use a combination spanner #21. Use a drive socket #21. Use a ratchet wrench.

20

Remove the fastening bolts.

21

Detach the lower control arm.

22

Remove the fastening bolt.

23

Remove the upper control arm.

24

Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.

25



Install a new upper control arm.

Replacement: rear upper arm – Mercedes ML W163. Professionals recommend:

- During the installation process, use only new bolts and nuts.
- Do not damage the ball joint cover.
- Position the control arm according to its mounting holes.

26

Install the fastening bolts.

27

Attach the lower control arm. Use a flat screwdriver.

28

Install the fastening bolts. Use a hammer.

29

Connect the ball joint to the steering knuckle.

30

Screw the fasteners of the ball joint. Use a combination spanner #19.

31

Tighten the upper fastener of the shock absorber strut mount. Use a combination spanner #13. Use a drive socket #13. Use a torque wrench. Tighten it to 40 Nm torque.

32

Install the shock strut mount cap.

33

Tighten the top fastening of the ball joint. Use a combination spanner #19. Use a torque wrench. Tighten it to 70 Nm torque.

34

Screw in the fastener that connects the ABS sensor to the rear knuckle. Use a drive socket #10. Use a ratchet wrench.

35

Support the arm. Use a hydraulic transmission jack.

36

Tighten the lower arm fastening. Use a combination spanner #21. Use a drive socket #21. Use a torque wrench. Tighten it to 70 Nm torque.

37

Tighten the rear fastener connecting the control arm to the subframe. Use a combination spanner #18 (2 pieces). Use a torque wrench. Tighten it to 75 Nm torque.

38

Tighten the front fastener connecting the control arm to the subframe. Use a combination spanner #18 (2 pieces). Use a torque wrench. Tighten it to 75 Nm torque.

39

Remove the support from under the arm.

AUTODOC recommends:

- Replacement: rear upper arm – Mercedes ML W163. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

40

Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #13. Use a torque wrench. Tighten it to 55 Nm torque.

41

install the rod fastening to the stabilizer and tighten it. Use a combination spanner #13. Use a torque wrench. Tighten it to 55 Nm torque.

42

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.

43

Clean the brake disk surface. Use a brake cleaner.

Replacement: rear upper arm – Mercedes ML W163. Tip from AUTODOC:

- After applying the spray, wait a few minutes.

44

Install the wheel.

AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. Mercedes ML W163

45

Screw in the wheel bolts. Use wheel impact socket #17.

46

Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 nm torque.

47

Remove the jacks and chocks.

DID YOU FIND THESE INSTRUCTIONS HELPFUL?

YES NO

BECOME A MEMBER OF AUTODOC CLUB!

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR MERCEDES

CONTROL ARM: A WIDE SELECTION

CHOOSE CAR PARTS FOR MERCEDES ML W163

CONTROL ARM FOR MERCEDES: BUY NOW

CONTROL ARM FOR MERCEDES ML W163: THE BEST DEALS & OFFERS

ⓘ Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.