




How to change rear  
brake pads on  
**MERCEDES-BENZ C-  
Class T-modell (S202)** –  
replacement guide

## SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle


### Important!

This replacement procedure can be used for:  
MERCEDES-BENZ C-Class T-modell (S202) C 230 T (202.083)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: MERCEDES-BENZ E-Class Saloon (W124) E 250 D (124.126, 124.129)

REPLACEMENT: BRAKE PADS – MERCEDES-BENZ C-CLASS T-MODELL (S202). TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- All-purpose cleaning spray
- Ceramic grease
- Torque wrench
- Combination spanner #17
- Drive socket # 13
- Drive socket # 17
- HEX bit No.H5
- Wheel impact socket #17
- Ratchet wrench
- Flat Screwdriver
- Pin punch
- Hammer
- Tap wrench
- Long nose pliers
- Crow bar
- Wheel chock

**Buy tools**

Replacement: brake pads – MERCEDES-BENZ C-Class T-modell (S202).  
AUTODOC recommends:

- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- All work should be done with the engine stopped.

**REPLACEMENT: BRAKE PADS – MERCEDES-BENZ C-CLASS T-MODELL (S202). USE THE FOLLOWING PROCEDURE:**

**1** Open the bonnet.

**2** Unscrew the brake fluid reservoir cap.



**3** Secure the wheels with chocks.

**4** Loosen the wheel bolts. Use wheel impact socket #17. Use a tap wrench.



**5** Raise the car.

**AUTODOC recommends:**

- If you are using a jack, make sure it rests on a flat surface without any unevenness.
- Be sure to additionally secure the car with jack stands.

**6**

Unscrew the wheel bolts.



**Replacement: brake pads – MERCEDES-BENZ C-Class T-modell (S202). Tip:**

- To avoid injury, hold up the wheel when unscrewing the bolts.


**7**

Remove the wheel.



8

Clean the brake pad guide pins. Use a wire brush. Use all-purpose cleaning spray.




9

Remove the brake pad guide pins. Use a pin punch. Use a hammer.




10

Remove the retaining spring of the brake pads.




11

Spread the brake pads. Use a crowbar (2 pieces).



12

Remove the brake pads.



**AUTODOC recommends:**


- Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

**13** Clean the mounting seats of the brake pads on the brake caliper bracket. Use a wire brush. Use a brake cleaner.


**AUTODOC recommends:**

- Replacement: brake pads – MERCEDES-BENZ C-Class T-modell (S202). After applying the spray, wait a few minutes.

**14** Install new brake shoes.



**15** Install the retaining spring of the brake pads.



**16** Install the brake pad guide pins. Use a pin punch. Use a hammer.



**17** Clean the brake disk surface. Use a brake cleaner.



**18** Treat the surface where the brake disc contacts the wheel rim. Use ceramic grease.



**19** Install the wheel.



**AUTODOC recommends:**

- Important! Hold the wheel while screwing in the fastening bolts. MERCEDES-BENZ C-Class T-modell (S202)



20

Screw in the wheel bolts. Use wheel impact socket #17. Use a ratchet wrench.



21

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 110 Nm torque.



22

Remove the jacks and chocks.



### AUTODOC recommends:

- MERCEDES-BENZ C-Class T-modell (S202) – Press the brake pedal several times with the engine shut down until you feel the resistance built up.
- Check the brake fluid level in the expansion tank and top up if necessary.

23

Tighten the brake fluid reservoir cap.



24

Close the bonnet.

Replacement: brake pads – MERCEDES-BENZ C-Class T-modell (S202). Tip from AUTODOC experts:

- Slow down smoothly for first 150-200 km after the brake pads replacement. Avoid unnecessary and sharp braking to a stop.

**WELL DONE!** 

[VIEW MORE TUTORIALS](#)

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  
**Google Play**

 Download on the  
**App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**BRAKE PADS: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.