- AUTODOC CLUB

How to change fuel filter on **CITROËN C4 II (B7)** – replacement guide



SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: CITROËN C4 II (B7) 1.6 VTi 120, CITROËN C4 II (B7) 1.4 VTi 95, CITROËN C4 II (B7) 1.6 THP 155, CITROËN C4 II (B7) 1.6 VTi 120 LPG, CITROËN C4 II (B7) 1.2 THP 130, CITROËN C4 II (B7) 1.2 THP 110, CITROËN C4 II (B7) 1.6

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: PEUGEOT 206 Hatchback (2A/C) 1.6



ß

O

+ AUTODOC CLUB



Replacement: fuel filter – CITROËN C4 II (B7). Tip from AUTODOC experts:

- Ensure adequate ventilation of the workplace. Fuel vapors are poisonous.
- Please note: all work on the car CITROËN C4 II (B7) should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:



Open the fuel door.



Unscrew the fuel filler cap.





Lift the car using a jack or place it over an inspection pit.

4

Prepare a container for fluids.







Clean the fasteners of the fuel supply lines. Use all-purpose cleaning spray.



6

Remove the fuel lines from the car body.



7

Squeeze the clips and detach the fuel supply lines from the fuel filter housing. Use fuel line pliers. Use a crowbar.



Replacement: fuel filter – CITROËN C4 II (B7). Tip from AUTODOC experts:

• Be careful! Fuel may leak from the filter housing and hoses.

+ AUTODOC CLUB





Remove the fuel filter. Use a crowbar.



9

Put the old filter cartridge in the container.

10

Install a new fuel filter.



Replacement: fuel filter – CITROËN C4 II (B7). AUTODOC experts recommend:

- Make sure that the fuel filter is positioned correctly. Consider the fuel flow direction mark.
- During installation, take care to prevent dust and dirt from getting into the fuel filter housing.
- Take care to only use quality filters.



Connect the fuel supply lines to the fuel filter.



+ AUTODOC CLUB



12

Install the fuel lines on the car body.



13

Take the fluid container away from under the fuel filter.



14

Lower the car.

15

Tighten the fuel filler cap.



16

Close the fuel door.

Replacement: fuel filter - CITROËN C4 II (B7). Tip from AUTODOC:

• Before starting off, switch the ignition on and off several times. This should be done to activate the fuel pump to make it pump fuel through the fuel system.



Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.



Shut off the engine.

18

Replacement: fuel filter - CITROËN C4 II (B7). Tip from AUTODOC experts:

• To protect the environment from pollution, be sure to dispose of the used filters at special collection points.



VIEW MORE TUTORIALS



AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

FUEL FILTER: A WIDE SELECTION

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.