+ AUTODOC CLUB

How to change ignition coil on MERCEDES-BENZ W124 Estate (S124) – replacement guide







SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for: MERCEDES-BENZ W124 Estate (S124) 300 TE 3.0 4-matic (124.290), MERCEDES-BENZ W124 Estate (S124) 300 TE 3.0 (124.090), MERCEDES-BENZ W124 Estate (S124) 260 TE 2.6 FGST., MERCEDES-BENZ W124 Estate (S124) 260 TE FGST. 2.6

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: MERCEDES-BENZ 190 (W201) 2.0 (201.023)

CLUB.AUTODOC.CO.UK 1-8







REPLACEMENT: IGNITION COIL - MERCEDES-BENZ W124 ESTATE (S124). TOOLS YOU'LL NEED:



- Wire brush
- High-temperature anti-seize lubricant
- Dielectric grease
- Torque wrench
- Combination spanner #10
- Drive socket # 10

- Spark plug socket # 16
- Ratchet wrench
- Phillips screwdriver
- Crow bar
- Fender cover

Buy tools

CLUB.AUTODOC.CO.UK 2-8







Replacement: ignition coil – MERCEDES-BENZ W124 Estate (S124). Tip from AUTODOC:

 Warning! Shut down the engine before starting any work – MERCEDES-BENZ W124 Estate (S124).

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

- 1 Open the bonnet.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Disconnect the earth cable terminal from the battery. Use a combination spanner #10.



Unscrew the inlet pipe fasteners. Use a Phillips screwdriver. Use a drive socket #10. Use a ratchet wrench.



Remove the fastening bolts.



CLUB.AUTODOC.CO.UK 3-8







6 Remove the inlet pipe.



Remove the ignition coil cover.



Disconnect the high tension cable from the ignition coil.



Unscrew the fasteners of the ignition coil terminals. Use a drive socket #10. Use a ratchet wrench.



Disconnect the terminals from the ignition coil.

10



CLUB.AUTODOC.CO.UK 4-8







Unscrew the ignition coil fasteners. Use a combination spanner #10.



Remove the ignition coil.



13 Install a new ignition coil.



Screw in the ignition coil fasteners. Use a combination spanner #10.



Connect the terminals to the ignition coil.



CLUB.AUTODOC.CO.UK 5-8







Treat the ignition coil terminals. Use dielectric grease.



Screw in the ignition coil terminals. Use a drive socket #10. Use a ratchet wrench.



Connect the high tension cable to the ignition coil.



19 Fit the ignition coil cover.



Attach the inlet pipe.



CLUB.AUTODOC.CO.UK 6-8







21 Install the fastening bolts.



Screw in the inlet pipe fasteners. Use a Phillips screwdriver. Use a drive socket #10. Use a ratchet wrench.



Connect the earth cable terminal to the battery.



- Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.
- 25 Shut off the engine.
- Remove the fender protection cover.
- Close the bonnet.




VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 7-8





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

IGNITION COIL: A WIDE SELECTION

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.

CLUB.AUTODOC.CO.UK 8-8