



How to change rear
wheel bearing on **OPEL**
Tigra Twintop (X04) –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

OPEL Tigra Twintop (X04) 1.4, OPEL Tigra Twintop (X04) 1.8, OPEL Tigra Twintop (X04) 1.3 CDTI

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: OPEL Corsa D Hatchback (S07) 1.3 CDTI (L08, L68)

REPLACEMENT: WHEEL BEARING – OPEL TIGRA
TWINTOP (X04). TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- All-purpose cleaning spray
- Copper grease
- Torx bit T30
- Drive socket # 32
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Tap wrench
- Hammer
- Crow bar
- Rubber mallet
- Wheel chock

Buy tools

Replacement: wheel bearing – OPEL Tigra Twintop (X04). AUTODOC recommends:

- Do not re-use the bearing assembly of your OPEL Tigra Twintop (X04) car.
- The wheel hub bearing replacement procedure is identical for both wheels on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: WHEEL BEARING – OPEL TIGRA TWINTOP (X04). USE THE FOLLOWING PROCEDURE:

1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the rear of the car and secure on supports.


4 Unscrew the wheel bolts.



AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. OPEL Tigra Twintop (X04)


5 Remove the wheel.




6 Clean the brake drum fasteners. Use a wire brush. Use WD-40 spray.



7 Unscrew the brake drum fastening Use Torx T30. Use a ratchet wrench.




8 Remove the brake drum.



Replacement: wheel bearing – OPEL Tigra Twintop (X04). Tip:

- Examine the brake drum. Replace it if necessary.


9 Remove the hub bearing protection cap. Use a crowbar. Use a hammer.




Replacement: wheel bearing – OPEL Tigra Twintop (X04). AUTODOC experts recommend:

- Some cars are not equipped with wheel hub caps.


10 Unscrew the wheel hub axle nut. Use a drive socket #32. Use a tap wrench.




11 Remove the fastening nut.




12 Remove the hub and the bearing together, since they are a sealed unit.



13 Clean the hub bearing mounting seat. Use a wire brush. Use all-purpose cleaning spray.



14 Install the new wheel hub with a bearing.



15 Install the fastening nut.



16

Tighten the hub. Use a drive socket #32. Use a torque wrench. Tighten it to 280 nm torque.




Replacement: wheel bearing – OPEL Tigra Twintop (X04). Tip from AUTODOC:

- The wheel bearing unit must not tilt on the axle pin.
- Important! Be sure to use new fasteners.


17

Install the hub bearing protection cap. Use a rubber mallet.



18

Treat the wheel hub in the area where it contacts the brake drum. Use copper grease.




19 Install a brake drum.



20 Tighten the brake drum fasteners. Use Torx T30. Use a torque wrench. Tighten it to 4 Nm torque.



21 Clean the wheel rim mounting seat. Use a wire brush.



22 Treat the surface where the wheel rim contacts the brake drum. Use copper grease.



23 Install the wheel.



AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. OPEL Tigra Twintop (X04)

24

Screw in the wheel bolts. Use wheel impact socket #17.




25

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 110 Nm torque.



26

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

WHEEL BEARINGS : A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.