




How to change rear strut
mount on **Skoda Fabia**
6Y5 – replacement guide

VIDEO TUTORIAL

** Important!**

This replacement procedure can be used for:

SKODA ROOMSTER (5J) 1.2 TDI, SKODA OCTAVIA (1U2) 1.6, SKODA OCTAVIA (1U2) 1.8, SKODA OCTAVIA (1U2) 1.9 TDI, SKODA OCTAVIA (1U2) 1.9 SDI, SKODA Octavia I Combi (1U5) 1.6, SKODA Octavia I Combi (1U5) 1.8 20V, SKODA Octavia I Combi (1U5) 1.9 SDI, SKODA Octavia I Combi (1U5) 1.9 TDI, SKODA ROOMSTER Praktik (5J) 1.2 TSI, SKODA ROOMSTER Praktik (5J) 1.2 TDI, SKODA Octavia I Combi (1U5) 1.8 T, SKODA ROOMSTER (5J) 1.9 TDI, SKODA ROOMSTER Praktik (5J) 1.6 TDI, SKODA OCTAVIA (1U2) 1.8 T, (+ 82)

The steps may slightly vary depending on the car design.

REPLACEMENT: STRUT MOUNT – SKODA FABIA 6Y5.
LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #16
- Combination spanner #17
- Drive socket # 16
- Torx bit T25
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Adjustable wrench
- Vice
- Hydraulic transmission jack
- Wheel chock

BUY TOOLS

Replacement: strut mount – Skoda Fabia 6Y5. AUTODOC experts recommend:

- The replacement procedure is identical for the mounts of the right and left shock absorbers of the rear suspension.
- Both mounts of the rear shock struts should be replaced simultaneously.
- Be sure to replace all self-locking nuts and bolts during installation.
- All work should be done with the engine stopped.

REPLACEMENT: STRUT MOUNT – SKODA FABIA 6Y5. TAKE THE FOLLOWING STEPS:

1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3 Raise the rear of the car and secure on supports.



4 Unscrew the wheel bolts.




AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. Skoda Fabia 6Y5


5 Remove the wheel.



6 Unscrew and remove the wheel arch cover fasteners. Use Torx T25.



7 Remove the wheel arch cover.



8 Secure the rear axle beam. Use a hydraulic transmission jack.



9 Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.




10 Unscrew the lower fastener of the shock absorber. Use a combination spanner #16. Use a drive socket #16. Use a ratchet wrench.



11

Unscrew the upper fastener of the shock absorber. Use a drive socket #16. Use a ratchet wrench.



AUTODOC recommends:

- Skoda Fabia 6Y5 – To avoid injury, hold the shock absorber while unscrewing the fastening bolts.

12

Remove the shock absorber.



13

Clean the shock absorber rod fastener. Use a wire brush. Use WD-40 spray.




14

Grip the shock absorber in a vice.



15 Remove the shock absorber piston rod fastening. Use a combination spanner #17. Use an adjustable wrench.



16 Release the vice and take out the shock absorber.



17 Remove the shock absorber mount, boot and bump stop.



Replacement: strut mount – Skoda Fabia 6Y5. Tip from AUTODOC experts:

- Examine the shock absorber dust cap and the bump stop. Replace them if necessary.

18 Install the new mount, boot, and bump stop on the shock absorber.



19 Grip the shock absorber in a vice.



20 Screw the shock strut piston rod upper fastening. Use a combination spanner #17. Use an adjustable wrench. Use a torque wrench. Tighten it to 25 Nm torque.




21 Release the vice and take out the shock absorber.




22 Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



23 Treat the shock absorber mounting seats. Use copper grease.




24 Place the shock absorber in the wheel arch and secure it.



AUTODOC recommends:

- Important! Hold the shock absorber while screwing in the fastening bolts. Skoda Fabia 6Y5

25 Tighten the top shock absorber fastening. Use a drive socket #16. Use a torque wrench. Tighten it to 30 Nm torque.+90°



AUTODOC recommends:

- Important! Be sure to use new fasteners.

26 Treat the shock absorber fasteners. Use copper grease.



27 Clean the shock absorber mounting seats. Use WD-40 spray.

28 Tighten the lower fastener of the shock absorber. Use a drive socket #16. Use a combination spanner #16. Use a torque wrench. Tighten it to 40 Nm torque. +90°



AUTODOC recommends:

- Important! Be sure to use new fasteners.

29 Remove the mounting from under the rear axle beam.




AUTODOC recommends:

- Replacement: strut mount – Skoda Fabia 6Y5. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.


30

Install the wheel arch cover to its mounting seat.




31

Install and tighten the wheel arch cover fasteners. Use Torx T25.




32

Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.



33

Install the wheel.




Replacement: strut mount – Skoda Fabia 6Y5. Tip from AUTODOC experts:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.


34 Screw in the wheel bolts. Use wheel impact socket #17.



35 Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 nm torque.



36 Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON  **Google Play**

 **Download on the App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR SKODA

STRUT MOUNT: A WIDE SELECTION

CHOOSE CAR PARTS FOR SKODA FABIA 6Y5

STRUT MOUNT FOR SKODA: BUY NOW

STRUT MOUNT FOR SKODA FABIA 6Y5: THE BEST DEALS & OFFERS

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.