



How to change tailgate
struts on **Peugeot 207**
hatchback –
replacement guide

VIDEO TUTORIAL




ⓘ Important!

This replacement procedure can be used for:

PEUGEOT 207 Hatchback 1.6, PEUGEOT 207 Hatchback 1.4, PEUGEOT 207 Hatchback 1.4 16V, PEUGEOT 207 Hatchback 1.6 16V, PEUGEOT 207 Hatchback 1.6 16V Turbo, PEUGEOT 207 Hatchback 1.6 HDi, PEUGEOT 207 Hatchback 1.4 HDi, PEUGEOT 207 Hatchback 1.6 16V VTi, PEUGEOT 207 Hatchback 1.6 16V RC, PEUGEOT 207 Hatchback 1.6 HDi 110

The steps may slightly vary depending on the car design.

REPLACEMENT: TAILGATE STRUTS – PEUGEOT 207
HATCHBACK. TOOLS YOU'LL NEED:



- WD-40 spray
- Flat Screwdriver
- Hydraulic transmission jack

BUY TOOLS

Replacement: tailgate struts – Peugeot 207 hatchback. Professionals recommend:

- Right and left gas struts of the boot lid should be replaced simultaneously.
- The replacement procedure is identical for the right and left gas struts of the boot lid.
- All work should be done with the engine stopped.

REPLACEMENT: TAILGATE STRUTS – PEUGEOT 207 HATCHBACK. USE THE FOLLOWING PROCEDURE:


1

Open the boot lid.




2

Support the boot lid. Use a hydraulic transmission jack.



3

Release the circlip connecting the gas strut to the boot lid. Use a flat screwdriver.



4

Release the circlip connecting the gas strut to the car body. Use a flat screwdriver.




AUTODOC recommends:

- To avoid any injuries, be sure to hold the boot lid while demounting the gas struts.


5

Remove the boot lid gas strut.



6

Clean the mounting seats of the boot strut. Use WD-40 spray.



7

Install the new boot lid gas strut.




Replacement: tailgate struts – Peugeot 207 hatchback. Tip:

- To avoid any injuries, be sure to hold the boot lid while installing the gas strut.


8

Snap on the circlip connecting the gas strut to the car body.




9

Snap on the circlip connecting the gas strut to the boot lid.



10

Release the circlip connecting the gas strut to the boot lid. Use a flat screwdriver.



11

Release the circlip connecting the gas strut to the car body. Use a flat screwdriver.



AUTODOC recommends:


- To avoid any injuries, be sure to hold the boot lid while demounting the gas struts.

12

Remove the boot lid gas strut.



13 Clean the mounting seats of the boot strut. Use WD-40 spray.




14 Install the new boot lid gas strut.


Replacement: tailgate struts – Peugeot 207 hatchback. AUTODOC recommends:

- To avoid any injuries, be sure to hold the boot lid while installing the gas strut.

15 Snap on the circlip connecting the gas strut to the car body.




16 Snap on the circlip connecting the gas strut to the boot lid.



17

Remove the hydraulic transmission jack.



AUTODOC recommends:

- Replacement: tailgate struts – Peugeot 207 hatchback. Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.
- Check the working condition of the boot lid gas springs after they are installed.

18

Close the lid of the luggage compartment.



WELL DONE! 👍

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

AUTODOC+

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR PEUGEOT

TAILGATE STRUTS: A WIDE SELECTION

CHOOSE CAR PARTS FOR PEUGEOT 207

TAILGATE STRUTS FOR PEUGEOT: BUY NOW

TAILGATE STRUTS FOR PEUGEOT 207: THE BEST DEALS & OFFERS

ⓘ DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2021 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.