- AUTODOC CLUB

How to change front brake discs on **Opel Corsa C** – replacement guide



VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

OPEL Meriva A (X03) 1.4 16V Twinport LPG (E75), OPEL Corsa C Hatchback (X01) 1.8 (F08, F68), OPEL Corsa C Hatchback (X01) 1.7 DTI (F08, F68), OPEL Corsa C Hatchback (X01) 1.4 (F08, F68), OPEL Combo C Box Body / Estate 1.7 DI 16V, OPEL Corsa C Van (X01) 1.7 DTI 16V (F08, W5L), OPEL Combo C Box Body / Estate 1.6, OPEL Combo C Box Body / Estate 1.7 DTI 16V, OPEL Meriva A (X03) 1.6 (E75), OPEL Combo C Tour 1.6, OPEL Combo C Tour 1.7 DI 16V, OPEL Combo C Tour 1.7 DTI 16V, OPEL Tigra Twintop (X04) 1.4, OPEL Tigra Twintop (X04) 1.8, OPEL Meriva A (X03) 1.4 16V Twinport (E75), (+ 10)

The steps may slightly vary depending on the car design.



REPLACEMENT: BRAKE DISCS – OPEL CORSA C. TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torx bit T30
- Drive socket # 12
- Drive socket # E18
- Wheel impact socket #17

- Brake caliper wind back tool
- Ratchet wrench
- Torque wrench
- Rubber mallet
- Tap wrench
- Crow bar
- Wheel chock

BUY TOOLS



Replacement: brake discs – Opel Corsa C. AUTODOC recommends:

- Replace the brake disks on the car Opel Corsa C in complete set for each axis. Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- All work should be done with the engine stopped.

REPLACEMENT: BRAKE DISCS – OPEL CORSA C. TAKE THE FOLLOWING STEPS:



Open the bonnet. Unscrew the brake fluid reservoir cap.



2

Secure the wheels with chocks.





Loosen the wheel mounting bolts. Use wheel impact socket #17.



4

Raise the front of the car and secure on supports.



5

Unscrew the wheel bolts.



AUTODOC recommends:

• Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. Opel Corsa C

6

Remove the wheel.





Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.



8

Spread the brake pads. Use a crowbar.



9

Unscrew the brake caliper fastening. Use a drive socket #12. Use a ratchet wrench.



10

Remove the brake caliper.



+ AUTODOC CLUB



Replacement: brake discs – Opel Corsa C. Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.





12

Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.





Unscrew the caliper bracket fastening. Use a drive socket #E18. Use a tap wrench.



14

Remove the caliper bracket.



15

Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.

16

Unscrew the brake disc fastening. Use Torx T30. Use a ratchet wrench.



17

Remove the brake disc.





Replacement: brake discs – Opel Corsa C. AUTODOC experts recommend:

• If necessary, use a rubber mallet.

18

Clean the hub. Use a wire brush. Treat the contacting surface. Use copper grease.



19

Install the brake disc.



20

Tighten the brake disc fastening. Use Torx T30. Use a torque wrench. Tighten it to 7 Nm torque.



21

Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.





AUTODOC recommends:

 Replacement: brake discs – Opel Corsa C. After applying the spray, wait a few minutes.

22

Install the brake caliper bracket.



23

Tighten the brake caliper bracket. Use a drive socket #E18. Use a torque wrench. Tighten it to 100 Nm torque.



24

Treat the brake caliper piston. Use a brake cleaner.

Replacement: brake discs - Opel Corsa C. Tip from AUTODOC:

• After applying the spray, wait a few minutes.



Press in the brake caliper piston. Use brake caliper wind back tool.



26

Install the brake pads.



27

Install the brake caliper and fix it.



28

Tighten the brake caliper fasteners. Use a drive socket #12. Use a torque wrench. Tighten it to 27 Nm torque.



AUTODOC recommends:

 Opel Corsa C – Without starting the engine, press the brake pedal several times until it feels firm.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



30

Clean the brake disk surface. Use a brake cleaner.



Replacement: brake discs – Opel Corsa C. Tip:

• After applying the spray, wait a few minutes.



Install the wheel.



Replacement: brake discs – Opel Corsa C. Tip from AUTODOC experts:

• To avoid injury, hold up the wheel when screwing in the fastening bolts.



Screw in the wheel bolts. Use wheel impact socket #17.



33

Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 110 Nm torque.



34

Remove the jacks and chocks.



AUTODOC recommends:

• Important! Replacement: brake discs – Opel Corsa C. Check the brake fluid level in the reservoir and top up if necessary.





Tighten the brake fluid reservoir cap. Close the hood.






VIEW MORE TUTORIALS



AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR OPEL

BRAKE DISCS: A WIDE SELECTION



CHOOSE CAR PARTS FOR OPEL CORSA C

BRAKE DISCS FOR OPEL: BUY NOW

BRAKE DISCS FOR OPEL CORSA C: THE BEST DEALS & OFFERS

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.