



How to change rear
shock absorbers on
CITROËN C4 Coupe
(LA_) – replacement
guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

CITROËN C4 Coupe (LA_) 1.4 16V, CITROËN C4 Coupe (LA_) 1.6 HDi

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: PEUGEOT 307 SW (3H) 2.0 HDi 135

REPLACEMENT: SHOCK ABSORBERS – CITROËN C4 COUPE (LA_). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #13
- Drive socket # 13
- Drive socket # 15
- Drive socket # 16
- Wheel impact socket #17
- Ratchet wrench
- Shock absorber socket #DD6
- Vice
- Hydraulic transmission jack
- Wheel chock

Buy tools

Replacement: shock absorbers – CITROËN C4 Coupe (LA_). Tip from AUTODOC experts:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- Please note: all work on the car – CITROËN C4 Coupe (LA_) – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the rear of the car and secure on supports.

4

Unscrew the wheel bolts.



Replacement: shock absorbers – CITROËN C4 Coupe (LA_). AUTODOC recommends:

- To avoid injury, hold up the wheel when unscrewing the bolts.

5

Remove the wheel.




6

Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.




7

Support the rear suspension beam. Use a hydraulic transmission jack.




8

Unscrew the lower fastener of the shock absorber. Use a combination spanner #13. Use a drive socket #15. Use a ratchet wrench.



9


Unscrew the upper fastener of the shock absorber. Use a drive socket #13. Use a ratchet wrench.




AUTODOC recommends:

- Important! Hold the shock absorber while unscrewing the fastening bolts.
CITROËN C4 Coupe (LA_)

10 Remove the fastening bolts.




11 Remove the shock absorber.



12 Grip the shock absorber in a vice.




13 Clean the shock absorber rod fastener. Use a wire brush. Use WD-40 spray.



- 14** Remove the shock absorber piston rod fastening. Use a shock absorber socket DDN#6. Use a drive socket #16. Use a ratchet wrench.



- 15** Remove the shock absorber mount, boot and bump stop.




AUTODOC recommends:

- Replacement: shock absorbers – CITROËN C4 Coupe (LA_). Carefully inspect the mount, the boot, and the bump stop of the shock absorber. Replace if necessary.
- Before installing a new shock absorber you should pump it manually 3-5 times.


- 16** Install the mount, boot and bump stop onto a new shock absorber.




- 17** Tighten the shock absorber rod nut. Use a shock absorber socket DDN[®]6. Use a drive socket #16. Use a torque wrench. Tighten it to 38 nm torque.




- 18** Treat the shock absorber rod fastener. Use copper grease.



- 19** Release the vice and take out the shock absorber.




- 20** Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



- 21** Treat the shock absorber mounting seats. Use copper grease.

22

Place the shock absorber in the wheel arch and secure it.




Replacement: shock absorbers – CITROËN C4 Coupe (LA_). Tip:

- To avoid injury, hold the shock absorber cautiously tight when screwing in the fastening bolts.


23

Install the fastening bolts.



24


Tighten the top shock absorber fastening. Use a drive socket #13. Use a torque wrench. Tighten it to 45 Nm torque.




25 Raise the hydraulic transmission jack by 10-15 cm.



26 Tighten the lower fastener of the shock absorber. Use a combination spanner #13. Use a drive socket #15. Use a torque wrench. Tighten it to 57 Nm torque.




27 Remove the mounting from under the rear axle beam.



AUTODOC recommends:

- Replacement: shock absorbers – CITROËN C4 Coupe (LA_). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

28 Treat the shock absorber fasteners. Use copper grease.



29

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



30

Clean the brake disk surface. Use a brake cleaner.



Replacement: shock absorbers – CITROËN C4 Coupe (LA_). Tip from AUTODOC:

- After applying the spray, wait a few minutes.

31

Install the wheel.




AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. CITROËN C4 Coupe (LA_)


32 Screw in the wheel bolts. Use wheel impact socket #17.



33 Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 100 Nm torque.



34 Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SHOCK ABSORBERS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.