



How to change
serpentine belt on **FIAT**
Siena (178_, 172_) –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!


This replacement procedure can be used for:

FIAT Siena (178_, 172_) 1.3 JTD

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FIAT Doblo Cargo (223_) 1.3 D Multijet

REPLACEMENT: SERPENTINE BELT – FIAT SIENA (178_, 172_). TOOLS YOU'LL NEED:



- Wire brush
- Copper grease
- Drive socket # 15
- Drive socket # E18
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Crow bar
- Wheel chock


Buy tools

Replacement: serpentine belt – FIAT Siena (178_, 172_). Tip from AUTODOC experts:


- All work should be done with the engine stopped.

REPLACEMENT: SERPENTINE BELT – FIAT SIENA (178_, 172_). USE THE FOLLOWING PROCEDURE:

1 Secure the wheels with chocks.



2 Loosen the wheel mounting bolts. Use wheel impact socket #17.



3 Raise the front of the car and secure on supports.

4 Unscrew the wheel bolts.




AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
FIAT Siena (178_, 172_)


5

Remove the wheel.




6

Pry up the hydraulic power steering belt. Use a crowbar. Turn the crankshaft pulley. Use a drive socket #E18. Use a ratchet wrench.




7

Remove the hydraulic power steering belt.




8

Clean the tensioner pulley of the V-ribbed belt. Use a wire brush.



9

Pull aside the V-ribbed belt tensioner pulley. Use a drive socket #15. Use a ratchet wrench.



10

Remove the V-ribbed belt.



11


Return the tensioner pulley to its initial position.

Replacement: serpentine belt – FIAT Siena (178_, 172_). AUTODOC recommends:

- Check the condition of the tensioner pulley and idler pulley. Replace them if necessary.

12


Install the V-ribbed belt.



AUTODOC recommends:

- Make sure that the V-ribbed belt fits all pulleys snugly.

13 Pull aside the V-ribbed belt tensioner pulley. Use a drive socket #15. Use a ratchet wrench.




14 Place the V-ribbed belt on the tensioner pulley.


15 Return the tensioner pulley to its initial position.




16 Install the hydraulic power steering belt. Turn the crankshaft pulley. Use a drive socket #E18. Use a ratchet wrench.



17 Treat the surface where the brake disc contacts the wheel rim. Use copper grease.




18 Install the wheel.




Replacement: serpentine belt – FIAT Siena (178_, 172_). Professionals recommend:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

19 Screw in the wheel bolts. Use wheel impact socket #17.



20 Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 98 nm torque.



21

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SERPENTINE BELT: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.