# - AUTODOC CLUB

How to change fuel filter on FORD Transit Connect V408 Van – replacement guide



#### SIMILAR VIDEO TUTORIAL




This video shows the replacement procedure of a similar car part on another vehicle

#### (i) Important!

This replacement procedure can be used for: FORD Transit Connect V408 Van 1.6 TDCi

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FORD Fiesta Mk6 Hatchback (JA8, JR8) 1.6 TDCi



O



# Replacement: fuel filter – FORD Transit Connect V408 Van. AUTODOC experts recommend:

• Ensure adequate ventilation of the workplace. Fuel vapors are poisonous.

• All work should be done with the engine stopped.

### **REPLACEMENT: FUEL FILTER – FORD TRANSIT CONNECT V408** VAN. USE THE FOLLOWING PROCEDURE:



Open the hood.

Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



Remove the engine cover.



# Replacement: fuel filter – FORD Transit Connect V408 Van. Tip from AUTODOC:

- Raise the engine cover, holding it on two sides simultaneously.
- Do not apply excessive force when removing the part. Otherwise you may damage it.



Unscrew the fuel filter bracket fixing bolts. Use a drive socket #8. Use a ratchet wrench.



5

Clean the fasteners of the fuel supply lines. Use all-purpose cleaning spray.



6

Detach the fuel pressure sensor connector.



7

Squeeze the clips and detach the fuel supply lines from the fuel filter housing. Use a flat screwdriver.



#### AUTODOC recommends:

• Be careful! Fuel may leak from the filter housing and hoses.

### + AUTODOC CLUB



8

Detach the fuel pressure sensor connector.



9

Loosen the fuel filter mounting. Use a drive socket #8. Use a ratchet wrench.



10

#### Remove the fuel filter.



11

Clean the fuel filter. Use all-purpose cleaning spray.



12

Unscrew the fasteners of the fuel filter housing cover. Use Torx T15. Use a ratchet wrench.



### + AUTODOC CLUB



13

Remove the fuel filter housing cover.



14

Clean the fuel filter housing and the cover. Use all-purpose cleaning spray.



15

Install and tighten the cap of the fuel filter housing. Use Torx T15. Use a ratchet wrench.



16

Install a new fuel filter.



Replacement: fuel filter – FORD Transit Connect V408 Van. AUTODOC experts recommend:

• Take care to only use quality filters.



Screw in the fuel filter mounting bracket. Use a drive socket #8. Use a ratchet wrench.



18

Attach the fuel pressure sensor connector.



19

Connect the fuel lines to the fuel filter and lock the fastening clips.



20

Connect the bleeder kit to the fuel filter bleeder screw.



21

Fill the new filter with fuel.



### + AUTODOC CLUB



22

Remove the bleeder kit.



23

Connect the fuel lines to the fuel filter and lock the fastening clips.



24

Attach the fuel pressure sensor connector.



25

Clean the fasteners of the fuel supply lines. Use all-purpose cleaning spray.



26

Screw the fixing bolts of the fuel filter bracket. Use a drive socket #8. Use a ratchet wrench.






Install the engine cover and secure it.



# Replacement: fuel filter – FORD Transit Connect V408 Van. Professionals recommend:

- Make sure the engine cover is properly seated. It should not be displaced with respect to the guiding fasteners.
- Do not apply excessive force when installing the part. Otherwise you may damage the fasteners.





# Replacement: fuel filter – FORD Transit Connect V408 Van. AUTODOC recommends:

• To protect the environment from pollution, be sure to dispose of the used filters at special collection points.



VIEW MORE TUTORIALS



#### AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



#### A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

#### **FUEL FILTER: A WIDE SELECTION**

### **i** DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.