



How to change the cabin
filter on the **FORD**
Transit Mk6 Minibus
(V347, V348) –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

FORD TRANSIT Bus 2.2 TDCi, FORD TRANSIT Bus 2.2 TDCi RWD, FORD TRANSIT Bus 2.4 TDCi, FORD TRANSIT Bus 2.4 TDCi 4x4, FORD TRANSIT Bus 3.2 TDCi

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: FORD TRANSIT MK-7 Box 2.2 TDCi

REPLACEMENT: POLLEN FILTER – FORD TRANSIT MK6
MINIBUS (V347, V348). TOOLS YOU NEED:



• Microfibre towel

• Fender cover

[Buy tools](#)

Replacement: pollen filter – FORD Transit Mk6 Minibus (V347, V348).
AUTODOC recommends:

- Replace the cabin filter at least once every six months, once in early spring and once in autumn.
- Follow the service intervals, recommendations, and requirements for using the part provided by the manufacturer.
- If the air flow into the cabin has sharply decreased or you use the car in a high dust or pollen area, replace the filter earlier than specified.
- All the work should be carried out with the ignition switched off.

REPLACEMENT: POLLEN FILTER – FORD TRANSIT MK6 MINIBUS (V347, V348). RECOMMENDED SEQUENCE OF STEPS:

1 Open the bonnet.

2 Use a fender protection cover to avoid damaging the paintwork and plastic parts of the car.

3 Pull out the old cabin filter.




4 Close off the air duct using a clean towel and clean the inside of the cabin filter housing. Use a microfibre towel.



5 Remove the rubber strip.



6 Install a new filter into the housing. Check the markings on the edge of the filter to make sure you are installing it the correct side up.



Replacement: pollen filter – FORD Transit Mk6 Minibus (V347, V348).
Professionals recommend:

- During installation, make sure to prevent dust and dirt from getting into the air filter housing.
- Make sure to only use quality filters.

7

Install the rubber strip.



8

Remove the fender cover.

9

Close the bonnet.

WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

POLLEN FILTER: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2024 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.