



How to change rear  
brake pads on **Renault  
Megane 2** – replacement  
guide

## VIDEO TUTORIAL



### Important!

This replacement procedure can be used for:

RENAULT Twingo II Hatchback 1.5 dCi 75, RENAULT Twingo II Hatchback 1.5 dCi 90, RENAULT Scénic III (JZ0/1\_) 1.5 dCi, RENAULT Grand Scénic III (JZ) 1.5 dCi, RENAULT Scénic III (JZ0/1\_) 1.5 dCi (JZ02, JZ0R), RENAULT Megane Scenic (JA) 1.6 16V, RENAULT Scénic I (JA0/1, FA0) 1.4 16V, RENAULT Scénic I (JA0/1, FA0) 2.0 16V RX4, RENAULT Scénic I (JA0/1, FA0) 1.9 dCi RX4, RENAULT Scénic I (JA0/1, FA0) 1.9 dTi, RENAULT Scénic I (JA0/1, FA0) 2.0 16V, RENAULT Scénic I (JA0/1, FA0) 1.9 dCi, RENAULT Scénic I (JA0/1, FA0) 1.8 16V, RENAULT Megane II Hatchback (BM, CM) 1.4 16V, RENAULT Megane II Hatchback (BM, CM) 1.6 16V, (+ 89)

The steps may slightly vary depending on the car design.

REPLACEMENT: BRAKE PADS – RENAULT MEGANE 2.  
TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- Combination spanner №15
- Drive socket # 13
- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Brake caliper wind back tool
- Crow bar
- Wheel chock

**BUY TOOLS**


Replacement: brake pads – Renault Megane 2. AUTODOC recommends:

- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- All work should be done with the engine stopped.

**REPLACEMENT: BRAKE PADS – RENAULT MEGANE 2. USE THE FOLLOWING PROCEDURE:**


1

Open the bonnet. Unscrew the brake fluid reservoir cap.




2

Secure the wheels with chocks.



3

Loosen the wheel mounting bolts. Use wheel impact socket #19.




4

Raise the rear of the car and secure on supports.



5

Unscrew the wheel bolts.




**AUTODOC recommends:**

- Important! Hold the wheel while unscrewing the fastening bolts. Renault Megane 2


6

Remove the wheel.



7

Spread the brake pads. Use a crowbar.




8

Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.



9

Unscrew the brake caliper fastening. Use a combination spanner #15. Use a drive socket #13. Use a ratchet wrench.



10

Remove the brake caliper.




Replacement: brake pads – Renault Megane 2. AUTODOC experts recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.


11

Remove the brake pads. Use a crowbar.



12

Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



AUTODOC recommends:

- Replacement: brake pads – Renault Megane 2. After applying the spray, wait a few minutes.

13

Treat the brake caliper bracket where it contacts the brake pads. Use anti-squeal paste.



14

Press in the brake caliper piston. Use brake caliper wind back tool.




Replacement: brake pads – Renault Megane 2. Tip from AUTODOC:

- Make sure the disc surface is clean before installing the pads.

15

Install new brake pads.





Replacement: brake pads – Renault Megane 2. Professionals recommend:

- Make sure the pads are installed with linings facing the disc.


- 16** Install the brake caliper and fix it. Use a combination spanner #15. Use a drive socket #13. Use a torque wrench. Tighten it to 35 Nm torque.



Replacement: brake pads – Renault Megane 2. AUTODOC experts recommend:

- Without starting the engine, press the brake pedal several times until you feel significant resistance.

- 17** Clean the brake disk surface. Use a wire brush. Use a brake cleaner.




Replacement: brake pads – Renault Megane 2. Tip:

- After applying the spray, wait a few minutes.

18

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



19

Install the wheel.



**AUTODOC recommends:**

- Important! Hold the wheel while screwing in the fastening bolts. Renault Megane 2


20

Screw in the wheel bolts. Use wheel impact socket #19.



21

Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 110 Nm torque.



22

Remove the jacks and chocks.



**AUTODOC recommends:**

- Important! Replacement: brake pads – Renault Megane 2. Check the brake fluid level in the reservoir and top up if necessary.

23

Tighten the brake fluid reservoir cap. Close the hood.



**Replacement: brake pads – Renault Megane 2. AUTODOC recommends:**

- Slow down smoothly for first 150-200 km after the brake pads replacement. Avoid unnecessary and sharp braking to a stop.

**WELL DONE!** 

**VIEW MORE TUTORIALS**

## AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

**AUTODOC**

GET IT ON  
**Google Play**

Download on the  
**App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**BUY SPARE PARTS FOR RENAULT**

**BRAKE PADS: A WIDE SELECTION**

**CHOOSE CAR PARTS FOR RENAULT MEGANE 2**

**BRAKE PADS FOR RENAULT: BUY NOW**

**BRAKE PADS FOR RENAULT MEGANE 2: THE BEST DEALS &  
OFFERS**

### **ⓘ DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.