



How to change front
brake pads on
**MERCEDES-BENZ C-
Class Coupe (CL203)** –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle


i Important!

This replacement procedure can be used for:
 MERCEDES-BENZ C-Class Coupe (CL203) C 30 CDI AMG (203.718), MERCEDES-BENZ C-Class Coupe (CL203) C 320 (203.764)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: MERCEDES-BENZ M-Class (W163) ML 270 CDI (163.113)

REPLACEMENT: BRAKE PADS – MERCEDES-BENZ C-CLASS COUPE (CL203). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- Nylon cleaning brush
- Brake cleaner
- Anti-squeal paste
- Copper grease
- Torque wrench
- Wheel impact socket #17
- Pin punch
- Hammer
- Rubber mallet
- Brake caliper wind back tool
- Crow bar
- Wheel chock

Buy tools

Replacement: brake pads – MERCEDES-BENZ C-Class Coupe (CL203).
AUTODOC experts recommend:


- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- Please note: all work on the car – MERCEDES-BENZ C-Class Coupe (CL203) – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Open the bonnet. Unscrew the brake fluid reservoir cap.

2 Secure the wheels with chocks.

3 Loosen the wheel mounting bolts. Use wheel impact socket #17.



4 Raise the front of the car and secure on supports.

5 Unscrew the wheel bolts.




AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
MERCEDES-BENZ C-Class Coupe (CL203)


6

Remove the wheel.



7

Detach the connector of the brake pad wear sensor.



Please note!

- Some cars are not equipped with the brake pad wear sensor.

8

Clean the brake caliper surface. Use a wire brush. Use a brake cleaner.




AUTODOC recommends:

- Replacement: brake pads – MERCEDES-BENZ C-Class Coupe (CL203). After applying the spray, wait a few minutes.


9

Remove the brake pads retaining clips. Use a pin punch. Use a hammer. Use a crowbar.



10

Remove the brake pads. Use a crowbar.



Replacement: brake pads – MERCEDES-BENZ C-Class Coupe (CL203). Tip from AUTODOC:

- Measure the brake disc thickness. Upon reaching the wear limit the part must be replaced.

11

Clean the brake caliper surface. Use a wire brush. Use a brake cleaner.



AUTODOC recommends:

- Replacement: brake pads – MERCEDES-BENZ C-Class Coupe (CL203). After applying the spray, wait a few minutes.

12

Treat the brake caliper piston. Use a nylon cleaning brush. Use a brake cleaner.




AUTODOC recommends:

- Replacement: brake pads – MERCEDES-BENZ C-Class Coupe (CL203). After applying the spray, wait a few minutes.

13

Press in the brake caliper piston. Use brake caliper wind back tool. Use a crowbar.



14

Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use anti-squeal paste.




Replacement: brake pads – MERCEDES-BENZ C-Class Coupe (CL203).
AUTODOC experts recommend:

- Make sure the disc surface is clean before installing the pads.

15

Install the brake pads.



Replacement: brake pads – MERCEDES-BENZ C-Class Coupe (CL203). Tip:

- Make sure the pads are installed with linings facing the disc.

16

Install the brake pads retaining clips. Use a rubber mallet.




17

Attach the connector of the brake pad wear sensor.



18 Clean the wheel rim mounting seat. Use a wire brush.



19 Treat the surface where the brake disc contacts the wheel rim. Use copper grease.




20 Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

- Replacement: brake pads – MERCEDES-BENZ C-Class Coupe (CL203). After applying the spray, wait a few minutes.

21 Install the wheel.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. MERCEDES-BENZ C-Class Coupe (CL203)

22

Screw in the wheel bolts. Use wheel impact socket #17.




23

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 150 Nm torque.



24

Remove the jacks and chocks.



Replacement: brake pads – MERCEDES-BENZ C-Class Coupe (CL203).
AUTODOC recommends:

- Without starting the engine, press the brake pedal several times until you feel significant resistance.
- Check the brake fluid level in the expansion tank and refill if necessary.

25

Tighten the brake fluid reservoir cap. Close the hood.



Replacement: brake pads – MERCEDES-BENZ C-Class Coupe (CL203). Tip
from AUTODOC:

- Slow down smoothly for first 150-200 km after the brake pads replacement. Avoid unnecessary and sharp braking to a stop.

WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BRAKE PADS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.