



How to change rear  
brake caliper on  
**MERCEDES-BENZ CLK**  
**(C209)** – replacement  
guide

## SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### Important!

This replacement procedure can be used for:

MERCEDES-BENZ CLK (C209) 200 1.8 Kompressor (209.342), MERCEDES-BENZ CLK (C209) 200 CGI 1.8 (209.343), MERCEDES-BENZ CLK (C209) 220 CDI 2.2 (209.308)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: MERCEDES-BENZ C-Class Saloon (W203) C 200 Kompressor (203.045)

REPLACEMENT: BRAKE CALIPER – MERCEDES-BENZ CLK (C209). TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- Drive socket # 16
- Combination spanner #9
- Combination spanner #14
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Brake bleeder kit
- Brake hose clip
- Pin punch
- Hammer
- Crow bar
- Wheel chock

[Buy tools](#)


Replacement: brake caliper – MERCEDES-BENZ CLK (C209). AUTODOC recommends:

- The replacement procedure is identical for the left and right brake calipers on the same axle.
- All work should be done with the engine stopped.

## REPLACEMENT: BRAKE CALIPER – MERCEDES-BENZ CLK (C209). RECOMMENDED SEQUENCE OF STEPS:

1

Open the bonnet. Unscrew the brake fluid reservoir cap.



2

Secure the wheels with chocks.




3

Loosen the wheel mounting bolts. Use wheel impact socket #17.



4 Raise the rear of the car and secure on supports.

5 Unscrew the wheel bolts.




Replacement: brake caliper – MERCEDES-BENZ CLK (C209). Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.


6 Remove the wheel.



7 Spread the brake pads. Use a crowbar.




- 8** Clean the area where the brake hose is connected to the caliper, and the guide pins area. Use a wire brush. Use a brake cleaner.




**AUTODOC recommends:**

- Replacement: brake caliper – MERCEDES-BENZ CLK (C209). After applying the spray, wait a few minutes.


- 9** Clamp the brake hose off using a brake hose clamp.



- 10** Put a container for gathering brake fluid beneath.



- 11** Loosen the brake hose fastening. Use a combination spanner #14.




12

Unscrew the brake caliper fastening. Use a drive socket #16. Use a ratchet wrench.




13

Remove the brake caliper.



14


Unscrew the brake hose from the brake caliper.



Replacement: brake caliper – MERCEDES-BENZ CLK (C209). AUTODOC experts recommend:


- When replacing a brake caliper it is recommended to replace brake pads, check the state of the brake discs and replace them with new ones if necessary.

**15** Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.




**16** While replacing the brake caliper on MERCEDES-BENZ CLK (C209), closely examine brake hoses for any signs of damage. Replace them if needed.

**17** Remove the brake pad retaining pin. Use a hammer. Use a pin punch.



**18** Remove the brake pads.



**19** If going to use the old brake pads, clean them. Use a wire brush. Use a brake cleaner.






Replacement: brake caliper – MERCEDES-BENZ CLK (C209). Tip:

- After applying the spray, wait a few minutes.

20

Treat the surface where the brake pads contact the brake caliper. Use anti-squeal paste.




21

Screw the brake caliper on the brake pipe.



22

Install the brake caliper and fix it.



23


Tighten the brake caliper fasteners. Use a drive socket #16. Use a torque wrench. Tighten it to 55 Nm torque.




- 24 Tighten the fastener connecting the brake pipe to the brake caliper. Use a combination spanner #14. Use a torque wrench. Tighten it to 18 Nm torque.




- 25 Install the brake pads.




- 26 Install the brake pad retaining pin. Use a hammer. Use a pin punch.



- 27 Remove the brake hose clamp.



**28** Undo the brake bleeder screw. Use a combination spanner #9.




**29** Connect the brake bleeder kit to the brake bleeder screw.



**30** Check the brake fluid level in the expansion tank and refill if necessary.




**31** Without starting the engine, press the brake pedal several times until you feel significant resistance.




**32** Bleed the brake caliper system.



**33** Tighten the brake bleeder screw. Use a combination spanner #9.



**34** Disconnect the brake bleeder kit.



**35** Clean the brake disk surface. Use a wire brush. Treat the contacting surface. Use copper grease.



**36** Install the wheel.




**AUTODOC recommends:**

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. MERCEDES-BENZ CLK (C209)


**37** Screw in the wheel bolts. Use wheel impact socket #17.



**38** Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 110 Nm torque.



**39** Remove the jacks and chocks.



Replacement: brake caliper – MERCEDES-BENZ CLK (C209). Professionals recommend:

- Check the brake fluid level in the expansion tank and refill if necessary.

40

Tighten the brake fluid reservoir cap. Close the hood.

**WELL DONE!** 

**VIEW MORE TUTORIALS**

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**BRAKE CALIPER: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.