



How to change  
serpentine belt on  
**Mercedes W201** –  
replacement guide

**VIDEO TUTORIAL**




** Important!**

This replacement procedure can be used for:

MERCEDES-BENZ 190 (W201) E 2.0 (201.024), MERCEDES-BENZ 190 (W201) 2.0 (201.023), MERCEDES-BENZ 190 (W201) E 2.0, MERCEDES-BENZ T1 Van (601, 611) 210 2.3, MERCEDES-BENZ T1 Van (601, 611) 210 D 2.8, MERCEDES-BENZ T1 Platform/Chassis (601) 210 D 2.9, MERCEDES-BENZ T1 Box (602) 310 D 2.9, MERCEDES-BENZ T1 Bus (601) 210 2.3, MERCEDES-BENZ T1 Bus (601) 210 D 2.8, MERCEDES-BENZ T1 Bus (602) 310 D 2.9, MERCEDES-BENZ T1 Platform/Chassis (601) 210 D 2.8, MERCEDES-BENZ T1 Platform/Chassis (602) 310 D 2.9, MERCEDES-BENZ T2/LN1 Box Body / Estate 510 2.3 (667.061, 667.062), MERCEDES-BENZ T2/LN1 Platform/Chassis 510 2.3 (667.001, 667.002), MERCEDES-BENZ T1/TN Platform/Chassis 410 D 2.9 (611.417, 611.418), (+ 2)

The steps may slightly vary depending on the car design.

REPLACEMENT: SERPENTINE BELT – MERCEDES  
W201. TOOLS YOU'LL NEED:



- Drive socket # 13
- Drive socket # 17
- Ratchet wrench
- Fender cover

**BUY TOOLS**

Replacement: serpentine belt – Mercedes W201. AUTODOC experts recommend:


- All work should be done with the engine stopped.

## REPLACEMENT: SERPENTINE BELT – MERCEDES W201. USE THE FOLLOWING PROCEDURE:


1 Open the bonnet.



2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.




3 Unscrew the fastening bolt of the belt tensioner. Use a drive socket #17. Use a ratchet wrench.




4

Loosen the belt tensioner. Use a drive socket #13. Use a ratchet wrench.



5

Remove the V-ribbed belt.




**AUTODOC recommends:**

- Check the condition of the tensioner pulley and idler pulley. Replace them if necessary.

6

Install the V-ribbed belt.




**Replacement: serpentine belt – Mercedes W201. Tip:**

- Make sure that the V-ribbed belt fits all pulleys snugly.

7

Tighten the belt tensioner. Use a drive socket #13. Use a ratchet wrench.



**AUTODOC recommends:**

- Make sure that the V-ribbed belt is properly tensioned.

8

Screw in the fastening bolt of the belt tensioner. Use a drive socket #17. Use a ratchet wrench.




9

Remove the fender protection cover.



10

Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.



**11**

Shut off the engine.

**12**

Close the hood.



**WELL DONE!** 

**VIEW MORE TUTORIALS**

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  **Google Play**

 **Download on the App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**BUY SPARE PARTS FOR MERCEDES**

**SERPENTINE BELT: A WIDE SELECTION**



**CHOOSE CAR PARTS FOR MERCEDES W201**

**SERPENTINE BELT FOR MERCEDES: BUY NOW**

**SERPENTINE BELT FOR MERCEDES W201: THE BEST DEALS  
& OFFERS**

### **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.