
+ AUTODOC CLUB

How to change camshaft position sensor on NISSAN Interstar Platform/Chassis – replacement guide





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:
NISSAN INTERSTAR Platform/Chassis 2.5 dCi 100, NISSAN INTERSTAR
Platform/Chassis dCi 115, NISSAN INTERSTAR Platform/Chassis dCi 120, NISSAN INTERSTAR Platform/Chassis dCi 150

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: RENAULT MASTER II Box (FD) 2.2 dCl 90

CLUB.AUTODOC.CO.UK 1–7







REPLACEMENT: CAMSHAFT POSITION SENSOR – NISSAN INTERSTAR PLATFORM/CHASSIS. TOOLS YOU'LL NEED:



- Wire brush
- All-purpose cleaning spray
- Electronic spray
- Torque wrench

- 10 mm socket
- Ratchet wrench
- Mounting lever
- Paper towels

Buy tools

CLUB.AUTODOC.CO.UK 2-7





Replacement: camshaft position sensor – NISSAN Interstar Platform/Chassis. AUTODOC recommends:

• All the work should be carried out with the ignition switched off.

REPLACEMENT: CAMSHAFT POSITION SENSOR – NISSAN INTERSTAR PLATFORM/CHASSIS. TAKE THE FOLLOWING STEPS:

- Lift the vehicle using a vehicle lift or place it over an inspection pit.
- Clean the fastener of the camshaft position sensor. Use a wire brush. Use an all-purpose cleaning spray.



Detach the connector of the camshaft position sensor.



Unscrew the fastener of the camshaft position sensor. Use a 10 mm socket. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 3-7





5 Remove the fastening bolt.



6 Remove the camshaft position sensor.



Plug the sensor mounting hole with a paper towel to prevent dust and dirt from getting in.



Clean the mounting seat of the camshaft position sensor. Use an all-purpose cleaning spray.



8

CLUB.AUTODOC.CO.UK 4-7





Treat the connector of the camshaft position sensor. Use an electronic spray.



- Remove the paper towel from the mounting hole.
- Install the new camshaft position sensor.



Install and screw in the fastening bolt. Use a 10 mm socket. Use a ratchet wrench.



Tighten the fastener of the camshaft position sensor. Use a 10 mm socket. Use a torque wrench. Tightening torque: 10 N·m.







Attach the connector of the camshaft position sensor.



- Lower the vehicle.
- Check that the new component is working.






VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 6-7



AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

CAMSHAFT POSITION SENSOR: A WIDE SELECTION

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2025 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.

CLUB.AUTODOC.CO.UK 7-7