



How to change pollen  
filter on **OPEL Astra F  
Classic Caravan (T92)** –  
replacement guide

### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

#### **Important!**


This replacement procedure can be used for:

OPEL Astra F Classic Caravan (T92) 1.4 i (F35, M35), OPEL Astra F Classic Caravan (T92) 1.6 i (F35, M35), OPEL Astra F Classic Caravan (T92) 1.6 i 16V (F35, M35)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: OPEL Corsa B Hatchback (S93) 1.4 i (F08, F68, M68)

REPLACEMENT: POLLEN FILTER – OPEL ASTRA F CLASSIC CARAVAN (T92). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Torque wrench
- Combination spanner #24
- Drive socket # 8
- Drive socket # 13
- Ratchet wrench
- Phillips Screwdriver
- Universal puller
- Fender cover

**Buy tools**

Replacement: pollen filter – OPEL Astra F Classic Caravan (T92). Tip from AUTODOC:


- Replace the cabin filter at least once every six months, in early spring and autumn seasons.
- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- If the air flow into the cabin has sharply reduced, replace the filter before a scheduled maintenance.
- Please note: all work on the car – OPEL Astra F Classic Caravan (T92) – should be done with the engine switched off.

**CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:**

**1** Remove the windscreen wiper arm nut covers.



**2** Clean the fasteners of the wiper arms. Use a wire brush. Use WD-40 spray.



**3** Unscrew the fasteners of the windscreen wiper arms. Use a drive socket #13. Use a ratchet wrench.




**4** Remove the wiper arms. Use a universal puller.




**5** Open the bonnet.

**6** Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

**7** Unscrew the fasteners of the cowl grille. Use a drive socket #8. Use a ratchet wrench. Use a Phillips screwdriver.



**8** Remove the wiper cowl grille located on the left side.



**9** Remove the wiper cowl grille located on the right side.



**10** Remove the cowl grille seal.



**11** Clean the plastic panel fasteners. Use a wire brush. Use WD-40 spray.



**12** Unscrew the plastic panel fasteners. Use a combination spanner #24.



**13** Remove the plastic panel.



**14** Press the pollen filter retaining clips to release them.




**15** Remove the cabin filter.




**16** Switch on the air recirculation mode.

**17** Clean the mounting seat of the cabin filter.




**18** Insert a new filter element into the filter housing.




**AUTODOC recommends:**

- Replacement: pollen filter – OPEL Astra F Classic Caravan (T92). Be sure to position the filtering element correctly. Avoid misalignment.
- Follow the air flow direction arrow on the filter.
- Attention! Use quality filters – OPEL Astra F Classic Caravan (T92).

**19** Lock the pollen filter retaining clips in place.



**20** Install the plastic panel.



**21** Screw on the plastic panel fasteners. Use a combination spanner #24.





**22** Install the wiper cowl grille located on the right side.




**23** Install the wiper cowl grille on the left side.



**24** Install and secure the cowl grille. Use a drive socket #8. Use a ratchet wrench. Use a Phillips screwdriver.




**25** Install the cowl grille seal.



**26** Remove the fender protection cover.

**27** Close the hood.

**28** Treat the wiper arm fasteners. Use copper grease.




**29** Install the wiper arms.



**30** Tighten the wiper arm fasteners. Use a drive socket #13. Use a torque wrench. Tighten it to 14 Nm torque.



**31** Install the nut covers of the windscreen wiper arms.



**32** Switch on the ignition.

**33**

Switch on the air conditioning system. This is necessary in order to make sure that the component operates properly.

**34**

Switch off the ignition.

**WELL DONE!** 

**VIEW MORE TUTORIALS**

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  
 **Google Play**

Download on the  
 **App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**POLLEN FILTER: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.