



How to change ignition
coil on **OPEL Mokka /
Mokka X (J13)** –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:

OPEL Mokka / Mokka X (J13) 1.8 4x4 (75), OPEL Mokka / Mokka X (J13) 1.8 (75),
OPEL Mokka / Mokka X (J13) 1.6 (75)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: OPEL Astra H Saloon (A04) 1.6 (L69)

REPLACEMENT: IGNITION COIL – OPEL MOKKA /
MOKKA X (J13). TOOLS YOU NEED:



- Electronic spray
- Torque wrench
- Torx bit T40
- Ratchet wrench
- Crow bar
- Fender cover

Buy tools

Replacement: ignition coil – OPEL Mokka / Mokka X (J13). AUTODOC experts recommend:


- The replacement procedure is the same for the ignition coils of all cylinders.
- Please note: all work on the car – OPEL Mokka / Mokka X (J13) – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Open the hood.

2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

3 Remove the engine cover.




AUTODOC recommends:

- Replacement: ignition coil – OPEL Mokka / Mokka X (J13). Do not use excessive force when removing the part as this may damage it.

4 Detach the connector from the ignition coil.




5 Unscrew the ignition coil bolts. Use Torx T40. Use a ratchet wrench.




6 Pry up the ignition coil. Use a crowbar.


7 Take out the ignition coil from the spark plug well.




8 Clean dirt, dust and debris from inside the spark plug wells.




9 Install the new ignition coil to the spark plug well.



10 Tighten the ignition coil bolts. Use Torx T40. Use a torque wrench. Tighten it to 7 nm torque.



11 Treat the ignition coil connector with electronic spray. The spray will protect the electrical contacts from corrosion, oxidation, and will reduce the contact resistance.




AUTODOC recommends:

- Replacement: ignition coil – OPEL Mokka / Mokka X (J13). After applying the spray, wait a few minutes.


12

Plug in the ignition coil connector.



13

Install the engine cover and secure it.



AUTODOC recommends:

- Replacement: ignition coil – OPEL Mokka / Mokka X (J13). Do not use excessive force during installation. This may damage the part.

14

Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

15

Shut off the engine.

16

Remove the fender protection cover.

17

Close the hood.

WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

IGNITION COIL: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.