



How to change front  
strut mount on **OPEL**  
**ZAFIRA B (A05)** –  
replacement guide

### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

#### **i Important!**

This replacement procedure can be used for:

OPEL ZAFIRA B (A05) 1.6 (M75), OPEL ZAFIRA B (A05) 2.0 (M75), OPEL ZAFIRA B (A05) 2.2 (M75), OPEL ZAFIRA B (A05) 1.9 CDTI (M75), OPEL ZAFIRA B (A05) 1.8 (M75), OPEL ZAFIRA B (A05) 1.6 CNG (M75), OPEL ZAFIRA B (A05) 1.7 CDTI (M75), OPEL ZAFIRA B (A05) 1.6 CNG Turbo (M75), OPEL ZAFIRA B (A05) 1.8 LPG (M75), OPEL ZAFIRA B (A05) 1.6 FlexFuel (M75)

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: OPEL Astra H Caravan (A04) 1.3 CDTI (L35)

**REPLACEMENT: STRUT MOUNT – OPEL ZAFIRA B (A05). LIST OF THE TOOLS YOU'LL NEED:**



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- HEX bit no.H5.
- Drive socket # 18
- Drive socket # 21
- Combination spanner #18
- Combination spanner #19
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Pliers
- Flat Screwdriver
- Rubber mallet
- Water pump pliers
- Hydraulic strut spring compressor
- Fender cover
- Wheel chock

**Buy tools**


Replacement: strut mount – OPEL ZAFIRA B (A05). Tip from AUTODOC experts:

- The replacement procedure is identical for the mounts of the left and right shock struts of the front suspension.
- All mounts of the front shock struts should be replaced simultaneously.
- All work should be done with the engine stopped.

**CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:**


1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the front of the car and secure on supports.

**4** Unscrew the wheel bolts.




**AUTODOC recommends:**

- Important! Hold the wheel while unscrewing the fastening bolts. OPEL ZAFIRA B (A05)

**5** Remove the wheel.



**6** Take out the retainer clip and move the brake hose out of the bracket on the shock strut. Use pliers. Use a flat screwdriver.




**7** Detach the ABS sensor connector. Use a flat screwdriver.




8

Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.




9

Unscrew the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #19. Use HEX No.H5. Use a ratchet wrench.



10

Remove the stabilizer rod.



11

Clean the fasteners connecting the shock strut to the steering knuckle. Use a wire brush. Use WD-40 spray.




**12**

Unscrew the fasteners connecting the suspension strut to the steering knuckle. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.




**13**

Remove the fastening bolts (2 pieces).



**14**

Disconnect the steering knuckle from the shock absorber strut.



**15**

Lower the car.

**16**

Open the bonnet.

**17**

Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.


**18**

Unscrew the top fastening of the shock strut mount. Use a flat screwdriver.



**19**

Remove the suspension strut.



**20**

Set the shock absorber strut on the spring compressor tool.

**Replacement: strut mount – OPEL ZAFIRA B (A05). Tip:**

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.

**21**

Compress the spring.




**22**

Remove the suspension strut mount cap. Use a flat screwdriver.







**23** Treat the shock strut rod. Use a wire brush. Use WD-40 spray.



**24** Remove the strut piston rod nut. Use a drive socket #21. Use a ratchet wrench.



**25** Remove the top strut mount. Use a flat screwdriver.




Replacement: strut mount – OPEL ZAFIRA B (A05). Tip from AUTODOC experts:


- Examine the shock absorber dust cap and the bump stop. Replace them if necessary.

**26** Clean the mounting seat of the shock strut mount. Use a wire brush. Use WD-40 spray.

**27** Install a new top shock strut mount.



**28** Tighten the shock strut piston rod nut. Use a drive socket #21. Use a torque wrench. Tighten it to 65 Nm torque.




Replacement: strut mount – OPEL ZAFIRA B (A05). AUTODOC experts recommend:

- Check to make sure the spring is positioned correctly. Avoid its misalignment.


**29** Treat the shock strut rod. Use copper grease.

**30** Decompress the spring.

**31** Remove the assembled shock strut.



**32** Install the shock strut into the wheel arch.



**33** Screw the top fastening of the shock strut mount. Use water pump pliers.



**34** Install the suspension strut mount cap.



**35** Remove the fender protection cover.

**36** Close the hood.

**37** Raise the front of the car and secure on supports.


**38** Treat the shock strut mounting seat on the steering knuckle. Use a wire brush. Use WD-40 spray.

**39** Fix the shock absorber strut on the steering knuckle.

**40** Install the fastening bolts (2 pieces).




**41** Tighten the lower fasteners connecting the shock strut to the steering knuckle. Use a combination spanner #18. Use a drive socket #18. Use a torque wrench. Tighten it to 85 Nm torque.+90°




**AUTODOC recommends:**

- Important! Be sure to use new fasteners.


**42** Attach the ABS sensor connector.




**43** Fasten the brake hose on the strut.




**44** Attach the brake hose retainer clip. Use a rubber mallet.




**45** Install the transverse stabilizer link.



**46** Tighten the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #19. Use HEX No.H5. Use a torque wrench. Tighten it to 60 Nm torque.




**47** Treat the shock strut fasteners. Treat all joints of the stabiliser link. Use copper grease.



48

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



49

Clean the brake disk surface. Use a brake cleaner.




**AUTODOC recommends:**

- Replacement: strut mount – OPEL ZAFIRA B (A05). After applying the spray, wait a few minutes.

50


Install the wheel.




**Replacement: strut mount – OPEL ZAFIRA B (A05). AUTODOC recommends:**

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

**51** Screw in the wheel bolts. Use wheel impact socket #17.



**52** Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 110 nm torque.



**53** Remove the jacks and chocks.



**WELL DONE!** 

**VIEW MORE TUTORIALS**

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  
**Google Play**

Download on the  
**App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**STRUT MOUNT: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.