



How to change front
suspension strut on
RENAULT CLIO II Box
(SB0/1/2_) – replacement
guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!


This replacement procedure can be used for:

RENAULT CLIO II Box (SB0/1/2_) 1.9 D, RENAULT CLIO II Box (SB0/1/2_) 1.5 dCi

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: RENAULT CLIO II (BB0/1/2_, CB0/1/2_) 1.2

REPLACEMENT: SUSPENSION STRUT – RENAULT CLIO II BOX (SB0/1/2_). TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18
- Combination spanner #21
- Drive socket # 10
- Drive socket # 17
- Drive socket # 18
- Drive socket # 21
- HEX bit no.H6.
- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Hydraulic strut spring compressor
- Tap wrench
- Fender cover
- Wheel chock

Buy tools

Replacement: suspension strut – RENAULT CLIO II Box (SB0/1/2_).
Professionals recommend:

- Both shock struts of the front suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock struts of the front suspension.
- Warning! Shut down the engine before starting any work – RENAULT CLIO II Box (SB0/1/2_).

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Open the bonnet.

2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.


3 Clean the fasteners of the shock strut upper mount. Use a wire brush. Use WD-40 spray.



4 Loosen the upper fastener of the shock strut mount. Use HEX No.H6. Use a combination spanner #21. Use a ratchet wrench.



5 Secure the wheels with chocks.



6 Loosen the wheel mounting bolts. Use wheel impact socket #19.



7 Raise the front of the car and secure on supports.


8 Unscrew the wheel bolts.




Replacement: suspension strut – RENAULT CLIO II Box (SB0/1/2_). AUTODOC recommends:

- To avoid injury, hold up the wheel when unscrewing the bolts.

9 Remove the wheel.




10 Clean the fasteners connecting the shock strut to the steering knuckle. Use a wire brush. Use WD-40 spray.




11 Unscrew the lower fastener connecting the shock strut to the steering knuckle. Use a combination spanner #18. Use a drive socket #18. Use a tap wrench.



12 Unscrew the ABS cable holder. Use a drive socket #10. Use a ratchet wrench.




13 Remove the fastening bolts.



14 Disconnect the steering knuckle from the shock absorber strut.




15 Unscrew the top fastening of the shock strut mount. Use a drive socket #21.



AUTODOC recommends:

- RENAULT CLIO II Box (SB0/1/2_) – To avoid injury, hold the suspension strut while unscrewing the fastening bolts.

16 Remove the suspension strut.



17

Set the shock absorber strut on the spring compressor tool.



Replacement: suspension strut – RENAULT CLIO II Box (SB0/1/2_). AUTODOC experts recommend:

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.

18

Compress the spring.



19

Treat the shock strut rod. Use WD-40 spray.

20


Remove the strut piston rod nut. Use a drive socket #17. Use HEX No.H6. Use a ratchet wrench.



21 Remove the top strut mount.




22 Remove the shock absorber dust cap and the bump stop.




AUTODOC recommends:

- Replacement: suspension strut – RENAULT CLIO II Box (SB0/1/2_). Carefully inspect the mount, the boot, and the bump stop of the shock absorber. Replace if necessary.

23 Release the coil spring.



24 Remove the spring.



25

Remove the old shock absorber from the hydraulic coil spring compressor.



Replacement: suspension strut – RENAULT CLIO II Box (SB0/1/2_). Tip from AUTODOC experts:

- Before installing a new shock absorber you should pump it manually 3-5 times.


26

Install the new shock absorber on the hydraulic coil spring compressor.



27

Install the dust sleeve and the bump stop on the new shock absorber.




28

Install the spring on the shock absorber.




29 Compress the spring.



30 Install the upper strut mount and the strut mount bearing.




31 Tighten the shock strut piston rod nut. Use a drive socket #17. Use HEX No.H6. Use a torque wrench. Tighten it to 21 Nm torque.



Replacement: suspension strut – RENAULT CLIO II Box (SB0/1/2_). Tip:

- Check to make sure the spring is positioned correctly. Avoid its misalignment.


32 Decompress the spring.




33 Remove the assembled shock strut.



34 Install the shock strut into the wheel arch.




35 Screw the top fastening of the shock strut mount. Do not tighten it.



AUTODOC recommends:

- Important! Hold the suspension strut while screwing in the fastening bolts.
RENAULT CLIO II Box (SB0/1/2_)

36 Treat the shock strut mounting seat on the steering knuckle. Use a wire brush. Use WD-40 spray.




37 Fix the shock absorber strut on the steering knuckle.




38 Install the fastening bolts.




39 Screw in the fastener that connects the shock strut to the steering knuckle. Use a combination spanner #18. Use a drive socket #18.



40 Tighten the ABS cable holder. Use a drive socket #10. Use a ratchet wrench.




- 41 Tighten the lower fasteners connecting the shock strut to the steering knuckle. Use a combination spanner #18. Use a drive socket #18. Use a torque wrench. Tighten it to 110 Nm torque.




- 42 Treat the shock strut fasteners. Use copper grease.



- 43 Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



- 44 Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

- Replacement: suspension strut – RENAULT CLIO II Box (SB0/1/2_). After applying the spray, wait a few minutes.

45

Install the wheel.




AUTODOC recommends:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

46

Screw in the wheel bolts. Use wheel impact socket #19.




47


Lower the car.

48


Tighten the wheel bolts using a criss-cross pattern. Use a torque wrench. Tighten it to 90 Nm torque.



- 49 Tighten the upper fastener of the shock absorber strut mount. Use a drive socket #21. Use HEX No.H6. Use a torque wrench. Tighten it to 60 Nm torque.




- 50 Treat the fasteners of the shock strut mount. Use copper grease.



- 51 Remove the fender protection cover.

- 52 Close the hood.

- 53 Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SHOCK ABSORBERS: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.