



How to change front
lower arm on **RENAULT
Modus / Grand Modus
(F, JP)** – replacement
guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!


This replacement procedure can be used for:

RENAULT Modus / Grand Modus (F, JP) 1.5 dCi 90, RENAULT Modus / Grand Modus (F, JP) 1.2, RENAULT Modus / Grand Modus (F, JP) 1.6, RENAULT Modus / Grand Modus (F, JP) 1.5 dCi, RENAULT Modus / Grand Modus (F, JP) 1.4, RENAULT Modus / Grand Modus (F, JP) 1.2 16V, RENAULT Modus / Grand Modus (F, JP) 1.2 16V Hi-Flex

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: RENAULT Clio III Hatchback (BR0/1, CR0/1) 1.5 dCi

**REPLACEMENT: FRONT LOWER ARM – RENAULT
MODUS / GRAND MODUS (F, JP). LIST OF THE TOOLS
YOU'LL NEED:**



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #16
- Combination spanner #18
- Drive socket # 13
- Drive socket # 16
- Drive socket # E16
- Drive socket # 18
- Wheel impact socket #17
- Ratchet wrench
- Tap wrench
- Hammer
- Flat chisel
- Crow bar
- Hydraulic transmission jack
- Wheel chock

Buy tools

Replacement: front lower arm – RENAULT Modus / Grand Modus (F, JP).
AUTODOC recommends:

- The replacement procedure is identical for the left and right lower control arms.
- All work should be done with the engine stopped.

REPLACEMENT: FRONT LOWER ARM – RENAULT MODUS / GRAND MODUS (F, JP). RECOMMENDED SEQUENCE OF STEPS:

1 Secure the wheels with chocks.



2 Loosen the wheel mounting bolts. Use wheel impact socket #17.



3 Raise the front of the car and secure on supports.


4 Unscrew the wheel bolts.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
RENAULT Modus / Grand Modus (F, JP)

5 Remove the wheel.




6 Clean all joints of the arm. Use a wire brush. Use WD-40 spray.



Replacement: front lower arm – RENAULT Modus / Grand Modus (F, JP). Tip:

- After applying the spray, wait a few minutes.
- Wear protective goggles.


7 Unscrew the subframe reinforcement bracket fasteners. Use a drive socket #13. Use a ratchet wrench.




8 Support the subframe. Use a hydraulic transmission jack.



9 Unscrew the subframe fastening. Use a drive socket #18. Use a ratchet wrench.



10 Detach the front subframe crossmember.



11 Remove the support from under the subframe.

AUTODOC recommends:

- Replacement: front lower arm – RENAULT Modus / Grand Modus (F, JP). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

12

Clean all joints of the arm. Use a wire brush. Use WD-40 spray.



Replacement: front lower arm – RENAULT Modus / Grand Modus (F, JP). Tip from AUTODOC experts:


- After applying the spray, wait a few minutes.
- Wear protective goggles.

13


Unscrew the ball joint fastening to the steering knuckle. Use a combination spanner #16. Use a drive socket #16. Use a tap wrench.




14 Remove the fastening bolt.



15 Unscrew the rear fastener connecting the control arm to the subframe. Use a combination spanner #18. Use a drive socket #18. Use a tap wrench.




16 Remove the rear fastener of the control arm.




17 Unscrew the front arm fastener. Use a combination spanner #18. Use a drive socket #E16. Use a tap wrench.

18 Remove the front fastener of the control arm. Use a crowbar.

19 Release the fastener connecting the ball joint to the steering knuckle. Use a flat metal-working chisel. Use a hammer.



20 Disconnect the ball joint from the steering knuckle.




21 Remove the arm.



22 Clean the mounting seats and the thread of the suspension arm. Use a wire brush. Use WD-40 spray.



23 Install a new arm.



Replacement: front lower arm – RENAULT Modus / Grand Modus (F, JP).
 AUTODOC experts recommend:

- During the installation process, use only new bolts and nuts.
- Do not damage the ball joint cover.

24

Install the front fastener of the arm.




25

Connect the ball joint to the steering knuckle.



26

Install the fastening bolt.



- 27 Screw the fasteners of the ball joint. Use a combination spanner #16. Use a drive socket #16. Use a ratchet wrench.




- 28 Install the rear fastener of the control arm.

- 29 Screw the rear arm fastener. Use a combination spanner #18. Use a drive socket #18. Use a ratchet wrench.



- 30 Screw the front arm fastener. Use a drive socket #18. Use a ratchet wrench.

- 31 Support the subframe. Use a hydraulic transmission jack.



- 32 Attach the front subframe crossmember.

- 33 Screw in the subframe fasteners. Use a drive socket #18. Use a ratchet wrench.


- 34 Remove the support from under the subframe.

AUTODOC recommends:

- RENAULT Modus / Grand Modus (F, JP) – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.


35

Support the arm. Use a hydraulic transmission jack.



36

Tighten the front fastener connecting the control arm to the subframe. Use a combination spanner #18. Use a drive socket #E16. Use a torque wrench. Tighten it to 70 Nm torque.



37


Tighten the rear fastener connecting the arm to the body subframe. Use a combination spanner #18. Use a drive socket #18. Use a torque wrench. Tighten it to 105 Nm torque.



- 38** Tighten the ball joint fastener. Use a combination spanner #16. Use a drive socket #16. Use a torque wrench. Tighten it to 60 Nm torque.



- 39** Remove the support from under the arm.



Replacement: front lower arm – RENAULT Modus / Grand Modus (F, JP).
AUTODOC experts recommend:

- Lower the hydraulic transmission jack smoothly, without jerks, to avoid damaging assemblies and mechanisms.

- 40** Support the subframe. Use a hydraulic transmission jack.




41

Unscrew the subframe fastening. Use a drive socket #18. Use a ratchet wrench.



42

Screw in the subframe reinforcement bracket fasteners. Use a drive socket #13. Use a ratchet wrench.




43

Tighten the subframe fastening. Use a drive socket #18. Use a torque wrench. Tighten it to 105 Nm torque.



44

Tighten the subframe reinforcement bracket fasteners. Use a drive socket #13. Use a torque wrench. Tighten it to 35 Nm torque.



45

Remove the support from under the subframe.

Replacement: front lower arm – RENAULT Modus / Grand Modus (F, JP).
Professionals recommend:

- Lower the hydraulic transmission jack smoothly, without jerks, to avoid damaging assemblies and mechanisms.

46

Treat all joints of the arm. Use copper grease.



47

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



48

Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

- After applying the spray, wait a few minutes.

49

Install the wheel.




AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. RENAULT Modus / Grand Modus (F, JP)

50

Screw in the wheel bolts. Use wheel impact socket #17.




51

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 105 nm torque.

52

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

CONTROL ARM: A WIDE SELECTION

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.