



How to change front
suspension strut on
SKODA Fabia II
Hatchback (542) –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

SKODA Fabia II Hatchback (542) 1.2 12V, SKODA Fabia II Hatchback (542) 1.2, SKODA Fabia II Hatchback (542) 1.4, SKODA Fabia II Hatchback (542) 1.6, SKODA Fabia II Hatchback (542) 1.4 TDI, SKODA Fabia II Hatchback (542) 1.9 TDI, SKODA Fabia II Hatchback (542) 1.2 TSI, SKODA Fabia II Hatchback (542) 1.6 TDI, SKODA Fabia II Hatchback (542) 1.4 TSI RS, SKODA Fabia II Hatchback (542) 1.2 TDI

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: SKODA Fabia I Combi (6Y5) 1.2

REPLACEMENT: SUSPENSION STRUT – SKODA FABIA II HATCHBACK (542). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Drive socket # 13
- Drive socket # 16
- Drive socket # 18
- 12-point socket # 36
- HEX bit No.H5.
- HEX bit No.H7.
- Combination spanner #16
- Combination spanner #18
- Combination spanner #21
- Wheel impact socket #17
- Shock absorber socket
- Ratchet wrench
- Torque wrench
- Tap wrench
- Pin punch
- Hammer
- Crow bar
- Hydraulic strut spring compressor
- Hydraulic transmission jack
- Fender cover
- Wheel chock

[Buy tools](#)

Replacement: suspension strut – SKODA Fabia II Hatchback (542). AUTODOC recommends:

- Both shock struts of the front suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock struts of the front suspension.
- All work should be done with the engine stopped.

REPLACEMENT: SUSPENSION STRUT – SKODA FABIA II HATCHBACK (542). RECOMMENDED SEQUENCE OF STEPS:

1 Open the bonnet.

2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

3 Loosen the upper fastener of the shock strut mount. Use a drive socket #13. Use a ratchet wrench.




4 Secure the wheels with chocks.



5

Loosen the wheel mounting bolts. Use wheel impact socket #17.



6

Remove the hub bearing protection cap.




Please note!

- Some cars are not equipped with wheel hub caps.

7

Unscrew the hub lock nut. Use drive 12-point socket #36. Use a tap wrench.



8

Raise the front of the car and secure on supports.

9

Unscrew the wheel bolts.



Replacement: suspension strut – SKODA Fabia II Hatchback (542). Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.


10

Remove the wheel.




11.1

Clean the fasteners connecting the stabiliser link to the shock strut, and those connecting the shock strut to the steering knuckle.



11.2


Use a wire brush. Use WD-40 spray.



- 12** Unscrew the nut and remove the stabilizer rod from the shock strut. Use a combination spanner #16. Use HEX No.H5. Use a ratchet wrench.



- 13** Unscrew the lower fastener connecting the shock strut to the steering knuckle. Use a combination spanner #18. Use a drive socket #18. Use a tap wrench.




- 14** Detach the brake hose from the shock strut. Use a crowbar.



- 15** Remove the fastening bolt.



- 16 Release the lower fastener connecting the shock strut to the steering knuckle. Use a special drive socket to remove the shock absorber. Use a ratchet wrench.




- 17 Clean the ball joint mounting seat. Use a wire brush. Use WD-40 spray.




- 18 Unscrew the fastener connecting the ball joint to the suspension control arm. Use a drive socket #13. Use a ratchet wrench.



- 19 Prop up the steering knuckle. Use a hydraulic transmission jack.




20 Disconnect the spherical joint from the arm. Use a crowbar.




21 Unscrew the fastener connecting the drive shaft to the wheel hub. Use drive 12-point socket #36.



22 Treat the mounting seat of the driveshaft on the steering knuckle. Use WD-40 spray.



23 Pull the drive shaft out of the steering knuckle and lifting it, tie to the body. Use a pin punch. Use a hammer.




Replacement: suspension strut – SKODA Fabia II Hatchback (542). AUTODOC experts recommend:

- Make sure that the drive shaft is not unloaded (when the car is jacked).


24

Disconnect the steering knuckle from the shock absorber strut. Use a pin punch. Use a hammer.



25

Lower the hydraulic transmission jack by 10-15 cm.



AUTODOC recommends:

- SKODA Fabia II Hatchback (542) – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.
- Make sure that the steering knuckle is not released from load.

26

Unscrew the top fastening of the shock strut mount. Use a drive socket #13. Use a ratchet wrench.




AUTODOC recommends:

- SKODA Fabia II Hatchback (542) – To avoid injury, hold the suspension strut while unscrewing the fastening bolts.


27

Remove the suspension strut.



28

Set the shock absorber strut on the spring compressor tool.



Replacement: suspension strut – SKODA Fabia II Hatchback (542). Tip from AUTODOC experts:

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.

29

Compress the spring.




30

Clean the shock absorber rod. Use a wire brush. Use WD-40 spray.



31

Remove the strut piston rod nut. Use a combination spanner #21. Use HEX No.H7. Use a ratchet wrench.



32 Remove the shock absorber mount, boot and bump stop.



33 Release the coil spring.



34 Remove the spring.



35 Remove the old shock absorber from the hydraulic coil spring compressor.



Replacement: suspension strut – SKODA Fabia II Hatchback (542).
Professionals recommend:

- Thoroughly examine the shock absorber mount, dust boot, bump stop. Replace them if necessary.
- Before installing a new shock absorber you should pump it manually 3-5 times.


36

Install the new shock absorber on the hydraulic coil spring compressor.



37

Install the dust sleeve and the bump stop on the new shock absorber.



38

Install the spring on the shock absorber.



39 Compress the spring.



40 Install the upper strut mount and the strut mount bearing.




41 Tighten the shock strut piston rod nut. Use a combination spanner #21. Use HEX No.H7. Use a torque wrench. Tighten it to 60 Nm torque.



Replacement: suspension strut – SKODA Fabia II Hatchback (542). AUTODOC experts recommend:

- Check to make sure the spring is positioned correctly. Avoid its misalignment.


42 Decompress the spring.




43 Remove the assembled shock strut.



44 Install the shock strut into the wheel arch.



45 Screw the top fastening of the shock strut mount. Do not tighten it.




AUTODOC recommends:

- Important! Hold the suspension strut while screwing in the fastening bolts.
SKODA Fabia II Hatchback (542)


46

Treat the shock strut mounting seat on the steering knuckle. Use a wire brush. Use WD-40 spray.



47

Fix the shock absorber strut on the steering knuckle.



48

Prop up the steering knuckle. Use a hydraulic transmission jack.




49

Clean the splines of the drive shaft CV joint. Use WD-40 spray.




50

Install the drive shaft.



51 Remove the support from under the steering knuckle.



Replacement: suspension strut – SKODA Fabia II Hatchback (542). Tip from AUTODOC experts:

- Lower the hydraulic transmission jack smoothly, without jerks, to avoid damaging assemblies and mechanisms.


52 Install and tighten a new bolt of the steering knuckle. Use a drive socket #18. Use a combination spanner #18. Use a torque wrench. Tighten it to 60 Nm torque.+90°



AUTODOC recommends:

- Important! Be sure to use new fasteners.

53 Treat the shock strut fasteners. Use copper grease.



54 Attach the ball joint to the control arm.



55 Tighten the ball joint fastener. Use a drive socket #13. Use a torque wrench. Tighten it to 20 Nm torque.+90°



AUTODOC recommends:

- Important! Be sure to use new fasteners.

56 Screw the nut of the drive shaft. Use drive 12-point socket #36.



- 57 Secure the stabilizer link on the suspension strut. Use a combination spanner #16. Use HEX #H5. Use a torque wrench. Tighten it to 40 Nm torque.




- 58 Fasten the brake hose on the strut.



- 59 Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.



- 60 Install the wheel.



AUTODOC recommends:


- Important! Hold the wheel while screwing in the fastening bolts. SKODA Fabia II Hatchback (542)

61 Screw in the wheel bolts. Use wheel impact socket #17.



62 Lower the car.


63 Tighten the upper fastener of the shock absorber strut mount. Use a drive socket #13. Use a torque wrench. Tighten it to 15 Nm torque. +90°



AUTODOC recommends:

- Important! Be sure to use new fasteners.

64 Screw the wheel hub lock nut. Use drive 12-point socket #36. Use a torque wrench. Tighten it to 50 Nm torque. +45°



AUTODOC recommends:

- Important! Be sure to use new fasteners.

65

Tighten the wheel bolts using a criss-cross pattern. Use a torque wrench. Tighten it to 120 Nm torque.



66

Remove the fender protection cover.

67

Close the hood.

68

Remove the jacks and chocks.



WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING

AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SHOCK ABSORBERS: A WIDE SELECTION

(i) DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.