




How to change front anti  
roll bar links on **SKODA  
Superb II Estate (3T5)** –  
replacement guide

### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

#### **i Important!**

This replacement procedure can be used for:

SKODA Superb II Estate (3T5) 1.4 TSI, SKODA Superb II Estate (3T5) 1.8 TSI, SKODA Superb II Estate (3T5) 1.8 TSI 4x4, SKODA Superb II Estate (3T5) 3.6 V6 4x4, SKODA Superb II Estate (3T5) 2.0 TDI 16V, SKODA Superb II Estate (3T5) 2.0 TDI, SKODA Superb II Estate (3T5) 2.0 TDI 4x4

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: SKODA Octavia II Combi (1Z5) 1.8 TSI

**REPLACEMENT: ANTI ROLL BAR LINKS – SKODA SUPERB II ESTATE (3T5). TOOLS YOU NEED:**



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18
- HEX bit no.H5.
- XZN socket bit # 6
- Drive socket # 18
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Wheel chock

**Buy tools**

Replacement: anti roll bar links – SKODA Superb II Estate (3T5). AUTODOC recommends:

- Replace the stabiliser links on SKODA Superb II Estate (3T5) in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

## REPLACEMENT: ANTI ROLL BAR LINKS – SKODA SUPERB II ESTATE (3T5). TAKE THE FOLLOWING STEPS:


1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the front of the car and secure on supports.


**4** Unscrew the wheel bolts.




Replacement: anti roll bar links – SKODA Superb II Estate (3T5). Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.

**5** Remove the wheel.




**6** Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.



- 7** Unscrew the fastener connecting the stabilizer link to the shock strut. Use a drive socket #18. Use a ratchet wrench.



- 8** Unscrew the fasteners connecting the stabiliser link to the stabiliser bar. Use a combination spanner #18. Use XZN #6. Use a ratchet wrench.



- 9** Remove the stabilizer rod.



Replacement: anti roll bar links – SKODA Superb II Estate (3T5). Professionals recommend:

- Examine stabiliser bushes. Replace them if needed.


**10** Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.




**11** Install a new rod, tighten the fasteners. Use a combination spanner #18. Use a drive socket #18. Use HEX No.H5. Use a ratchet wrench.



**12** Tighten the fastener connecting the stabilizer link to the shock strut. Use a drive socket #18. Use a torque wrench. Tighten it to 60 Nm torque.




**13** Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #18. Use a torque wrench. Tighten it to 60 Nm torque.





**14** Treat all joints of the stabiliser link. Use copper grease.



**15** Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



**16** Clean the brake disk surface. Use a brake cleaner.



**AUTODOC recommends:**

- Replacement: anti roll bar links – SKODA Superb II Estate (3T5). After applying the spray, wait a few minutes.

**17** Install the wheel.






Replacement: anti roll bar links – SKODA Superb II Estate (3T5). AUTODOC experts recommend:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.


18

Screw in the wheel bolts. Use wheel impact socket #17.




19

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



20

Remove the jacks and chocks.



**WELL DONE!** 

**VIEW MORE TUTORIALS**

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  
 **Google Play**

 **Download on the App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**ANTI ROLL BAR LINKS: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.