



How to change an exterior front door handle on the **Ford Transit Mk7 van** – replacement guide

VIDEO TUTORIAL



Important!

This replacement procedure can be used for:

FORD TRANSIT Bus 2.2 TDCi, FORD TRANSIT Bus 2.2 TDCi RWD, FORD TRANSIT MK-7 Box 2.2 TDCi, FORD TRANSIT MK-7 Box 2.2 TDCi RWD, FORD TRANSIT MK-7 Box 2.2 TDCi 4x4, FORD TRANSIT MK-7 Platform/Chassis 2.2 TDCi, FORD TRANSIT MK-7 Platform/Chassis 2.2 TDCi RWD, FORD TRANSIT MK-7 Platform/Chassis 2.2 TDCi 4x4, FORD TRANSIT Bus (FD_ , FB_ , FS_ , FZ_ , FC_) 2.4 DI RWD (F_B_ , F_C_ , F_A_), FORD TRANSIT Bus (FD_ , FB_ , FS_ , FZ_ , FC_) 2.4 DI, FORD TRANSIT Box (FA_) 2.4 DI, FORD TRANSIT Box (FA_) 2.4 DI RWD (FAA_ , FAB_ , FAC_ , FAD_), FORD TRANSIT Platform/Chassis (FM_ , FN_) 2.4 DI, FORD TRANSIT Bus (FD_ , FB_ , FS_ , FZ_ , FC_) 2.4 DI RWD (F_B_ , F_C_), FORD TRANSIT Bus (FD_ , FB_ , FS_ , FZ_ , FC_) 2.0 DI, (+ 31)

The steps may slightly vary depending on the car design.

REPLACEMENT: DOOR HANDLE – FORD TRANSIT MK7
VAN. TOOLS YOU'LL NEED:



- Electronic spray
- Torque wrench
- 10 mm socket
- Ratchet wrench
- Phillips screwdriver
- Plastic trim removal tool

BUY TOOLS

Replacement: door handle – Ford Transit Mk7 van. AUTODOC recommends:

- The replacement procedure is identical for the left and right front door handles.
- All the work should be carried out with the ignition switched off.

**REPLACEMENT: DOOR HANDLE – FORD TRANSIT MK7 VAN.
RECOMMENDED SEQUENCE OF STEPS:**


1

Open the car door.



2

Unscrew the fastener of the exterior door handle. Use a 10 mm socket. Use a ratchet wrench.



3

Remove the exterior door handle.




4 Transfer the lock rod to a new exterior door handle.



5 Install the new exterior door handle.



6 Tighten the door handle fastener. Use a 10 mm socket. Use a torque wrench. Tightening torque: 10 N·m.



7 Close the car door.



8 Check that the new component is working.

WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR FORD

DOOR HANDLE: A WIDE SELECTION

CHOOSE CAR PARTS FOR FORD TRANSIT MK7 VAN

DOOR HANDLE FOR FORD: BUY NOW

**DOOR HANDLE FOR FORD TRANSIT MK7 VAN: THE BEST
DEALS & OFFERS**

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2024 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.