



How to change rear
shock absorbers on
Volvo V70 SW –
replacement guide

VIDEO TUTORIAL

** Important!**

This replacement procedure can be used for:

VOLVO S80 I (184) 2.9, VOLVO S80 I (184) 2.8 T6, VOLVO S80 I (184) 2.4, VOLVO S80 I (184) 2.0 T, VOLVO S80 I (184) 2.5 TDI, VOLVO S80 I (184) 2.0, VOLVO V70 II (285) 2.3 T5, VOLVO V70 II (285) 2.4 T, VOLVO V70 II (285) 2.5 TDI, VOLVO V70 II (285) 2.4, VOLVO S60 I (384) 2.4, VOLVO S60 I (384) 2.4 T, VOLVO S60 I (384) 4.0 T5, VOLVO S80 I (184) 2.4 T, VOLVO S80 I (184) 2.4 D5, (+ 25)

The steps may slightly vary depending on the car design.

**REPLACEMENT: SHOCK ABSORBERS – VOLVO V70 SW.
TOOLS YOU NEED:**



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #18
- Torx bit T30
- Impact socket №18
- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Tap wrench
- Locking pliers
- Crow bar
- Hydraulic transmission jack
- Wheel chock


BUY TOOLS

Replacement: shock absorbers – Volvo V70 SW. Professionals recommend:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- All work should be done with the engine stopped.

REPLACEMENT: SHOCK ABSORBERS – VOLVO V70 SW. TAKE THE FOLLOWING STEPS:

1 Open the boot lid.



2 Move the folding shelf and detach it from the retainers. By doing this, you will get access to the side trim plastic panels.



3 Raise the lower lining of the boot.



4 Remove the boot front lower lining.




5 Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



6 Loosen the upper fastener of the shock absorber. Use a combination spanner #18. Use Torx T30. Use a ratchet wrench.



7 Secure the wheels with chocks.



8

Loosen the wheel mounting bolts. Use wheel impact socket #19.



9

Raise the rear of the car and secure on supports.



10

Unscrew the wheel bolts.




Replacement: shock absorbers – Volvo V70 SW. AUTODOC recommends:


- To avoid injury, hold up the wheel when unscrewing the bolts.

11


Remove the wheel.




12 Support the arm. Use a hydraulic transmission jack.



13 Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



14 Unscrew the lower fastener of the shock absorber. Use a drive socket #18. Use a tap wrench.




15 Unscrew the upper fastener of the shock absorber.




AUTODOC recommends:

- Important! Hold the shock absorber while unscrewing the fastening bolts. Volvo V70 SW

16 Remove the fastening bolt.




17 Remove the shock absorber. Use a crowbar.




Replacement: shock absorbers – Volvo V70 SW. Tip from AUTODOC experts:

- Before installing a new shock absorber you should pump it manually 3-5 times.

18 Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



19 Place the shock absorber in the wheel arch and fasten it.




Replacement: shock absorbers – Volvo V70 SW. Tip from AUTODOC:

- To avoid injury, hold the shock absorber cautiously tight when screwing in the fastening bolts.


20

Install the fastening bolt.



21

Screw in the lower fastener of the shock absorber. Use a drive socket #18.




22

Tighten the top shock absorber fastening. Use a combination spanner #18. Use a drive socket #18. Use locking pliers. Use a torque wrench. Tighten it to 60 Nm torque.



23

Tighten the lower fastener of the shock absorber. Use a drive socket #18. Use a torque wrench. Tighten it to 85 Nm torque.



24

Remove the support from under the arm.



AUTODOC recommends:

- Volvo V70 SW – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.

25

Treat the shock absorber fasteners. Use copper grease.



26

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



27

Clean the brake disc surface. Use a brake cleaner.




AUTODOC recommends:

- After applying the spray, wait a few minutes.

28

Install the wheel.



Replacement: shock absorbers – Volvo V70 SW. AUTODOC experts recommend:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.


29

Screw in the wheel bolts. Use wheel impact socket #19.




30


Lower the car.




31 Treat the shock absorber fasteners. Use copper grease.




32 Install the boot front lower lining.



33 Put down the lower lining of the boot.



34 Install the folding shelf to its mounting seat.




35 Close the lid of the luggage compartment.




36

Tighten the wheel bolts using a criss-cross pattern. Use a torque wrench. Tighten it to 140 nm torque.

**37**

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR VOLVO

SHOCK ABSORBERS: A WIDE SELECTION

CHOOSE CAR PARTS FOR VOLVO V70 SW

SHOCK ABSORBERS FOR VOLVO: BUY NOW

**SHOCK ABSORBERS FOR VOLVO V70 SW: THE BEST DEALS
& OFFERS**

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.