



How to change rear
shock absorbers on
Volvo V70 BW –
replacement guide

VIDEO TUTORIAL



Important!

This replacement procedure can be used for:

VOLVO V60 (155, 157) 2.0 T, VOLVO V60 (155, 157) 2.0 D3 / D4, VOLVO V60 (155, 157) 2.4 D5, VOLVO V60 (155, 157) 1.6 T3, VOLVO V60 (155, 157) 1.6 T4, VOLVO V60 (155, 157) 2.0 T5, VOLVO V70 III (135) 1.6 T4, VOLVO S80 II (124) 1.6 T4, VOLVO S80 II (124) 2.0 T5, VOLVO S80 II (124) 2.0 D3 / D4, VOLVO XC70 II Estate (136) 3.2 AWD, VOLVO XC70 II Estate (136) 3.0 T6 AWD, VOLVO V70 III (135) 2.0 T5, VOLVO S80 II (124) 3.2, VOLVO S60 II (134) 1.6 DRIVe / D2, (+ 76)

The steps may slightly vary depending on the car design.

**REPLACEMENT: SHOCK ABSORBERS – VOLVO V70 BW.
LIST OF THE TOOLS YOU'LL NEED:**



- Wire brush
- WD-40 spray
- Brake cleaner
- Ceramic grease
- Torque wrench
- Combination spanner #13
- Drive socket # 10
- Drive socket # 18
- Shock absorber socket #DD5.2
- Wheel impact socket #19
- Ratchet wrench
- Tap wrench
- Hydraulic transmission jack
- Wheel chock

BUY TOOLS

Replacement: shock absorbers – Volvo V70 BW. AUTODOC recommends:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- Please note: all work on the car – Volvo V70 BW – should be done with the engine switched off.


CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Secure the wheels with chocks.

2 Loosen the wheel bolts. Use wheel impact socket #19. Use a tap wrench.



3 Raise the car.



Replacement: shock absorbers – Volvo V70 BW. Tip:

- If you are using a jack, make sure it rests on a flat surface without any unevenness.
- Be sure to additionally secure the car with jack stands.

4

Unscrew the wheel bolts.




AUTODOC recommends:

- To avoid injury, hold up the wheel when unscrewing the bolts.

5

Remove the wheel.




6

Support the rear knuckle. Use a hydraulic transmission jack.




7

Clean the fasteners of the shock absorber upper mount. Use a wire brush. Use WD-40 spray.



8

Unscrew the shock absorber mount fasteners. Use a drive socket #10. Use a ratchet wrench.



9

Remove the fastening bolts.

10

Clean the lower shock absorber fastener. Use a wire brush. Use WD-40 spray.




11


Unscrew the lower fasteners of the shock absorber. Use a drive socket #18. Use a ratchet wrench.




12 Remove the fastening bolt.




13 Remove the shock absorber.




14 Clean the shock absorber mounting seats. Use a wire brush.




15 Grip the shock absorber in a vice.




16 Clean the shock absorber rod fastener. Use a wire brush. Use WD-40 spray.



- 17** Unscrew the fastener of the shock absorber piston rod. Use a combination spanner #13. Use a shock absorber socket #DD5.2. Use a ratchet wrench.



- 18** Remove the shock absorber mount, dust boot, and bump stop.



Replacement: shock absorbers – Volvo V70 BW. AUTODOC experts recommend:

- Thoroughly examine the shock absorber mount, dust boot, and bump stop. Replace them if necessary.


- 19** Install the mount, dust boot, and bump stop on a new shock absorber.



AUTODOC recommends:


- Before installing a new shock absorber you should pump it 3–5 times by hand.

20 Tighten the shock absorber rod nut. Use a combination spanner #13. Use a shock absorber socket #DD5.2. Use a torque wrench. Tighten it to 25 Nm torque.




21 Release the vice and take out the shock absorber.

22 Place the shock absorber in the wheel arch and secure it.




23 Install the fastening bolts.




24

For tightening the fasteners correctly, you have to jack up the suspension components to their working position. Use a hydraulic transmission jack.



25

Tighten the lower fastener of the shock absorber. Use a drive socket #18. Use a torque wrench. Tighten it to 150 Nm torque.



26

Tighten the shock absorber mount fasteners. Use a drive socket #10. Use a torque wrench. Tighten it to 30 Nm torque.




27

Remove the support from under the rear knuckle.

AUTODOC recommends:

- Volvo V70 BW – Do not lower the transmission jack sharply to avoid damaging components and mechanisms of the car.

28 Clean the wheel rim mounting seat. Use a wire brush.



29 Treat the surface where the brake disc contacts the wheel rim. Use ceramic grease.

30 Clean the brake disk surface. Use a brake cleaner.



31 Install the wheel.




Replacement: shock absorbers – Volvo V70 BW. Tip from AUTODOC experts:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.


32

Screw in the wheel bolts. Use wheel impact socket #19. Use a ratchet wrench.



33

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 140 Nm torque.



34

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON  **Google Play**

 **Download on the App Store**

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR VOLVO

SHOCK ABSORBERS: A WIDE SELECTION

CHOOSE CAR PARTS FOR VOLVO V70 BW

SHOCK ABSORBERS FOR VOLVO: BUY NOW

**SHOCK ABSORBERS FOR VOLVO V70 BW: THE BEST DEALS
& OFFERS**

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.