



How to change mass air  
flow sensor on  
**VAUXHALL Corsa Mk I  
(B) Hatchback (S93)** –  
replacement guide

## SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### Important!


This replacement procedure can be used for:

VAUXHALL Corsa Mk I (B) Hatchback (S93) 1.0 i 12V, VAUXHALL Corsa Mk I (B) Hatchback (S93) 1.2 i 16V

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: OPEL Corsa B Hatchback (S93) 1.4 i (F08, F68, M68)

REPLACEMENT: MASS AIR FLOW SENSOR – VAUXHALL CORSA MK I (B) HATCHBACK (S93). TOOLS YOU MIGHT NEED:



- Electronic spray
- Phillips Screwdriver
- Flat screwdriver
- Clic-R collar pliers
- Fender cover

**Buy tools**

Replacement: mass air flow sensor – VAUXHALL Corsa Mk I (B) Hatchback (S93). AUTODOC experts recommend:


- Clear the trouble codes from the electronic control unit if necessary.
- Make sure that no dust or dirt gets into the air duct components and the throttle body.
- Please note: all work on the car – VAUXHALL Corsa Mk I (B) Hatchback (S93) – should be done with the engine switched off.

**CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:**


**1** Open the bonnet.

**2** Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

**3** Detach the mass air flow sensor connector.




**4** Loosen the fastening clamp connecting the air duct to the air filter housing. Use a Phillips screwdriver.



**5** Detach the air duct housing from the air filter housing.



**6** Unfasten the clamps that secure the mass air flow sensor to the air hoses. Use a flat screwdriver.



**7** Remove the mass air flow sensor.



**8** Install a new mass air flow sensor.



**9** Attach the air duct.




Replacement: mass air flow sensor – VAUXHALL Corsa Mk I (B) Hatchback (S93). Tip:

- Set the new mass air flow sensor in the same position as the old one.


10

Fasten the clamps that secure the mass air flow sensor to the air hoses. Use clic-R collar pliers.




11

Screw the fastening clamp connecting the air duct to the air filter housing. Use a Phillips screwdriver.



12

Treat the mass air flow sensor connector. Use dielectric grease.



13

Attach the mass air flow sensor connector.



**14** Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

**15** Shut off the engine.

**16** Remove the fender protection cover.

**17** Close the hood.

**WELL DONE!** 

[VIEW MORE TUTORIALS](#)

# AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

**AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING**



**+ AUTODOC**

GET IT ON  
**Google Play**

 Download on the  
**App Store**

**Download**

**A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR**

**MASS AIR FLOW SENSOR: A WIDE SELECTION**

## **DISCLAIMER:**

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.