- AUTODOC CLUB

How to change rear shock absorbers on VAUXHALL Zafira Mk I (A) (T98) – replacement guide



SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for:

VAUXHALL Zafira Mk I (A) (T98) 1.8 Dualfuel, VAUXHALL Zafira Mk I (A) (T98) 1.6 16V, VAUXHALL Zafira Mk I (A) (T98) 1.8 16V, VAUXHALL Zafira Mk I (A) (T98) 2.0 DI 16V, VAUXHALL Zafira Mk I (A) (T98) 2.2 16V, VAUXHALL Zafira Mk I (A) (T98) 2.0 DTI 16V, VAUXHALL Zafira Mk I (A) (T98) 2.0 GSI Turbo, VAUXHALL Zafira Mk I (A) (T98) 2.0, VAUXHALL Zafira Mk I (A) (T98) 1.6 CNG, VAUXHALL Zafira Mk I (A) (T98) 1.6 Dualfuel

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: OPEL Zafira A (T98) 2.0 DI 16V (F75)



REPLACEMENT: SHOCK ABSORBERS – VAUXHALL ZAFIRA MK I (A) (T98). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Impact socket №E18
- Impact socket №E20

- Wheel impact socket #19
- Ratchet wrench
- Torque wrench
- Tap wrench
- Hydraulic transmission jack
- Wheel chock

Buy tools



Replacement: shock absorbers – VAUXHALL Zafira Mk I (A) (T98). AUTODOC recommends:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- All work should be done with the engine stopped.

REPLACEMENT: SHOCK ABSORBERS – VAUXHALL ZAFIRA MK I (A) (T98). USE THE FOLLOWING PROCEDURE:



Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #19.



3

Raise the rear of the car and secure on supports.





Unscrew the wheel bolts.



Replacement: shock absorbers – VAUXHALL Zafira Mk I (A) (T98). Tip:

• To avoid injury, hold up the wheel when unscrewing the bolts.



Remove the wheel.





Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



7

Support the rear suspension beam. Use a hydraulic transmission jack.





8

Unscrew the lower fastener of the shock absorber. Use a drive socket #E20. Use a tap wrench. Use a ratchet wrench.



9

Remove the fastening bolt.



10

Unscrew the upper fastener of the shock absorber. Use a drive socket #E18. Use a tap wrench. Use a ratchet wrench.



11

Remove the fastening bolt.



Replacement: shock absorbers – VAUXHALL Zafira Mk I (A) (T98). AUTODOC experts recommend:

• To avoid injuries, hold the shock absorber when undoing the fastening bolts.





Remove the shock absorber.



Replacement: shock absorbers – VAUXHALL Zafira Mk I (A) (T98). Tip from AUTODOC experts:

• Before installing a new shock absorber you should pump it manually 3-5 times.



Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



14

Place the shock absorber in the wheel arch and secure it.



AUTODOC recommends:

• Important! Hold the shock absorber while screwing in the fastening bolts. VAUXHALL Zafira Mk I (A) (T98)





Install the fastening bolt.



16

Screw the upper fastener of the shock absorber. Use a drive socket #E18. Use a ratchet wrench.



17

Install the fastening bolt.



18

Screw in the lower fastener of the shock absorber. Use a drive socket #E20. Use a ratchet wrench.



19

Raise the hydraulic transmission jack by 10-15 cm.





20

Tighten the lower fastener of the shock absorber. Use a drive socket #E20. Use a torque wrench. Tighten it to 110 Nm torque.



21

Tighten the top shock absorber fastening. Use a drive socket #18. Use a torque wrench. Tighten it to 90 Nm torque.



22

Remove the mounting from under the rear axle beam.



AUTODOC recommends:

 Replacement: shock absorbers – VAUXHALL Zafira Mk I (A) (T98). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

+ AUTODOC CLUB



23

Treat the shock absorber fasteners. Use copper grease.



24

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



25

Clean the brake disk surface. Use a brake cleaner.



Replacement: shock absorbers – VAUXHALL Zafira Mk I (A) (T98). Tip from AUTODOC:

• After applying the spray, wait a few minutes.

26

Install the wheel.





AUTODOC recommends:

• Important! Hold the wheel while screwing in the fastening bolts. VAUXHALL Zafira Mk I (A) (T98)

27

Screw in the wheel bolts. Use wheel impact socket #19.



28

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 110 nm torque.



29

Remove the jacks and chocks.





VIEW MORE TUTORIALS



AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

SHOCK ABSORBERS: A WIDE SELECTION

i DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.