



How to change rear
brake shoes on **VW
Caddy II Van (9K9A)** –
replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

VW Caddy II Van (9K9A) 60 1.4, VW Caddy II Van (9K9A) 1.9 SDI, VW Caddy II Van (9K9A) 75 1.6, VW Caddy II Van (9K9A) 1.9 TDI, VW Caddy II Van (9K9A) 1.7 SDI, VW Caddy II Van (9K9A) 1.9 D, VW Caddy II Van (9K9A) 1.4

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: SKODA OCTAVIA (1U2) 1.6

REPLACEMENT: BRAKE SHOES – VW CADDY II VAN (9K9A). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- High-temperature ceramic grease
- Torque wrench
- Torx bit T30
- Wheel impact socket #17
- Ratchet wrench
- Round-nose pliers
- Pliers
- Nippers
- Wheel chock


Buy tools

Replacement: brake shoes – VW Caddy II Van (9K9A). AUTODOC experts recommend:


- Replace brake shoes as a set on an axle. This will ensure efficient braking.
- The replacement procedure is identical for brake shoes on the same axle.
- Please note: all work on the car – VW Caddy II Van (9K9A) – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1 Secure the wheels with chocks.



2 Loosen the wheel mounting bolts. Use wheel impact socket #17.



3 Raise the rear of the car and secure on supports.

4

Unscrew the wheel bolts.



AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. VW Caddy II Van (9K9A)

5

Remove the wheel.




6

Clean the brake drum fasteners. Use a wire brush. Use WD-40 spray.

7


Unscrew the brake drum fastening. Use Torx T30. Use a ratchet wrench.




8 Remove the brake drum.



9 Pull both brake shoes with the adjuster from the working brake cylinder, avoiding damage to the boots. Use pliers.




10 Take out brake pad retainer springs from the holes. Use pliers.



11 Remove the lower return spring of brake shoes. Use pliers.

12 Remove both shoes from the mounting bracket. Use pliers.



Replacement: brake shoes – VW Caddy II Van (9K9A). Tip from AUTODOC:

- Don't press the brake pedal after removing the rear brake drum shoes. This will cause the piston to fall out of the brake cylinder, leakage of brake fluid and depressurization of the system.

13

Disconnect the parking brake cable.



14

Perform further demounting of the upper retaining spring and the adjuster mechanism. Use pliers.




15

Clean the fasteners of the brake shoes. Use a wire brush.

16

Install the upper retaining springs and adjustment mechanism on new brake shoes. Use pliers. Use round-nose pliers.



17 Clean the mounting seats of the brake shoes. Use a wire brush.

18 Treat the mounting seats of the brake shoes. Use copper grease.

19 Connect the parking brake cable to the parking brake lever. Use round-nose pliers.




20 Install the brake shoes on the working brake cylinder on the bracket and on the brake-support plate bracket.



21 Install the lower return spring. Use pliers.



22 Insert retaining springs into pin slots. Use pliers.



23 Clean the hub. Use a wire brush. Treat the contacting surface. Use copper grease.

24 Install a brake drum.




25 Tighten the brake drum fasteners. Use Torx T30. Use a torque wrench. Tighten it to 4 Nm torque.




26 Clean the wheel rim mounting seat. Use a wire brush.



27 Treat the surface where the wheel rim contacts the brake drum. Use high-temperature ceramic grease.



28 Install the wheel.




AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. VW Caddy II Van (9K9A)

29 Screw in the wheel bolts. Use wheel impact socket #17.




30 Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



31

Remove the jacks and chocks.



Replacement: brake shoes – VW Caddy II Van (9K9A). AUTODOC experts recommend:

- Slow down gently for the first 150–200 km after replacing the brake shoes. Avoid excessive and abrupt braking during that time.
- Adjust the gap between the brake shoes and the drum on VW Caddy II Van (9K9A), pressing the brake pedal 10-15 times.

WELL DONE! 

[VIEW MORE TUTORIALS](#)

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BRAKE SHOES: A WIDE SELECTION

i DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.