

How to change front anti roll bar links on **Citroen Xsara Picasso** – replacement guide





VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

CITROËN ZX Hatchback (N2) 1.9 D, CITROËN ZX Hatchback (N2) 1.9 TD, CITROËN ZX Hatchback (N2) 1.4 i, CITROËN ZX Hatchback (N2) 1.6 i, CITROËN ZX Hatchback (N2) 1.8 i, CITROËN ZX Hatchback (N2) 1.9 i, CITROËN ZX Hatchback (N2) 2.0 i, CITROËN ZX Hatchback (N2) 2.0 i 16V, CITROËN ZX Estate (N2) 1.9 D, CITROËN ZX Estate (N2) 1.8 i, CITROËN ZX Estate (N2) 1.4 i, CITROËN ZX Estate (N2) 1.9 TD, CITROËN ZX Estate (N2) 1.6 i, CITROËN Berlingo / Berlingo First I Van (M) 1.1 i, CITROËN Berlingo / Berlingo First I Van (M) 1.4 i, (+ 103)

The steps may slightly vary depending on the car design.





REPLACEMENT: ANTI ROLL BAR LINKS – CITROEN XSARA PICASSO. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease

- Drive socket # 17
- Wheel impact socket #19
- Torque wrench
- Wheel chock







AUTODOC recommends:

- Replace the stabiliser links on Citroen Xsara Picasso in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: ANTI ROLL BAR LINKS – CITROEN XSARA PICASSO. TAKE THE FOLLOWING STEPS:



Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #19.



3

Raise the front of the car and secure on supports.







Unscrew the wheel bolts.



AUTODOC recommends:

• Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. Citroen Xsara Picasso

5

Remove the wheel.



6

Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.



7

Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #17.







Unscrew the fastener connecting the stabilizer link to the shock strut. Use a drive socket #17.





Remove the stabilizer rod.



Replacement: anti roll bar links - Citroen Xsara Picasso. Tip from AUTODOC:

• Examine stabiliser bushes. Replace them if needed.



Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.







Install a new rod, tighten the fasteners.



12

Tighten the fastener connecting the stabilizer link to the shock strut. Use a drive socket #17. Use a torque wrench. Tighten it to 40 Nm torque.



13

Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #17. Use a torque wrench. Tighten it to 40 Nm torque.



14

Treat all joints of the stabiliser link. Use copper grease.







Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



16

Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

• Replacement: anti roll bar links – Citroen Xsara Picasso. After applying the spray, wait a few minutes.

17

Install the wheel.



AUTODOC recommends:

• Important! Hold the wheel while screwing in the fastening bolts. Citroen Xsara Picasso





Screw in the wheel bolts. Use wheel impact socket #17.



19

Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 100 nm torque.



20

Remove the jacks and chocks.






VIEW MORE TUTORIALS





AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR CITROEN

ANTI ROLL BAR LINKS: A WIDE SELECTION





CHOOSE CAR PARTS FOR CITROEN XSARA PICASSO

ANTI ROLL BAR LINKS FOR CITROEN: BUY NOW

ANTI ROLL BAR LINKS FOR CITROEN XSARA PICASSO: THE BEST DEALS & OFFERS

(i) **DISCLAIMER**:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.